



The Power of Reliability



Modular Power Series 2
Instruction Manual
855-347-000

SAFETY GUIDELINES

Principles of Safe Operation and Maintenance

Safety must always be the top priority of all personnel involved in the installation, operation, and maintenance of this unit as it operates at high voltages that could be potentially lethal. Technicians must adhere to the appropriate standards and manufacturer's recommendations to minimize hazards.

Do not attempt to perform the tasks described in this manual if you are not a qualified professional.

It is essential that all safety devices and emergency response systems be fully operational and within their certification periods before starting any service.

Visual Communication

This manual uses extensive visual aids and tries to adhere to ANSI and ISO safety symbol standards. These symbols describe the following situations:



WARNING indicates a hazardous situation that, if not avoided, may result in death or severe injury or damage to equipment and property.



CAUTION indicates a hazardous situation that, if not avoided, may result in minor or moderate injury or damage to equipment and property.



NOTICE indicates practices not related to physical injury but may result in equipment damage, environmental hazards, loss of data, and other undesirable consequences.



General Alerts

Risk of serious personal injury or damage to equipment and property. Always observe the following:

- Install and operate unit in a restricted access location. A restricted access location is an area to which access can be gained only by service personnel using a special tool, lock and key, or other means of security and which is controlled by the authority responsible for the location.
- Install the unit in locations where children are likely not to be present.
- Install chassis ground to the unit before connecting AC input.
- Installation, operation, and service must be done by qualified technicians, with all wiring and connections done in accordance with the local electrical codes.
- Input voltages can range up to 240 volts AC. All upstream AC, load and battery breakers must be shut OFF prior to installation. The system must be completely de-energized.
- All AC connections must conform to local codes and regulations.
- Use caution when handling unit under load as surfaces may be hot.



Always observe the following for applications requiring a backup battery:

- Use a battery with rating and capacity appropriate for the model of power supply in use.
- Use an appropriate DC overcurrent protection device in-line with the backup battery connection.
- Use wire and connectors rated for the maximum load current.
- Ensure battery polarity is correct before connecting.
- Do not attempt to charge a frozen battery.
- Handle batteries with care. Never short-circuit battery terminals.
- Always install batteries in well-ventilated areas.
- Always consult with and observe all battery manufacturer recommendations.



Risk of personal injury or damage to equipment and property. Always observe the following:

- Install in a protected environment and keep sources of moisture away from unit.
- Ensure the total power consumption of the load does not exceed the continuous rated capacity of the power supply output.
- Provide adequate support for the rear of the unit without obstructing the air inlet or outlet openings.
- Remove all metallic jewelry before working with the unit.
- Wear appropriate eye protection and always use appropriate tools during installation.
- DC-AC inverters should not be connected to any of the load connection points without a battery connected to the system. DC-AC inverters create significant inrush current and may damage the circuitry or interfere with the operation of power supplies when there is no battery connected. Connecting a DC-AC inverter in this way may void the product warranty. Do not connect DC-AC inverters to the outputs of the Load Distribution Module of the ICT units.



Risk of damage to equipment, environmental hazards, loss of data and other undesirable consequences. Always observe the following:

- The unit must be properly handled, mounted, and installed.
- Do not block air inlet or outlet openings.
- Due to environmental factors which are common at outdoor communications sites, power surges from lightning strikes, electrostatic discharge, and utility power feeds can occur. These surges can damage connected equipment.
- This product is compliant and certified to IEC61000-4-5 Surge Immunity, however, additional surge suppression methods must be followed to further protect this device.
- Third-party surge protection devices must be utilized to protect AC input power feeds, every exposed DC power conductor and exposed data cables. These protection devices must be installed at both ends of the exposed conductor, in close proximity to installed equipment. Periodically inspect these surge protection devices for proper function.
- Consult with manufacturers of surge protection devices to select appropriately rated protection device(s) and proper installation methods.
- ICT's product warranty does not cover damage caused by power surges and electrostatic discharge events including lightning.



NOTICE

NOTE: Due to the breaker-detection circuitry internal to the unit, it may be possible to measure a voltage on the terminal(s) with no load connected, even if that terminal's breaker is open circuit. This is normal operation. The breaker-detection circuitry is a high-impedance circuit, and while a voltage may be present on the output terminal, it is a signal voltage and does not support loading. A load device connected to the output will immediately pull this voltage to zero volts.

Product Alerts



Risk of serious personal injury or damage to equipment and property. Always observe the following:

- Operate the supply from a grounded 3-wire 120-volt AC or 230/240-volt AC source (50 or 60 Hz) with a branch circuit breaker rated 50 amps or less.
- If a lithium-ion battery is used, it must have an integrated battery management system (BMS) to protect the battery cells from inappropriate voltage or current levels.

GENERAL INFORMATION

Document Number: 855-347-000

Models:

ICT-IPSe-BMMD-LDM	ICT-IPSe-BMMD-LDMP
ICT-IPSe-BMM-LDM	ICT-IPSe-BMM-LDMP
ICT-IPSe-LDM-LDM	ICT-IPSe-LDM-LDMP
ICT-IPSe-BMMD	ICT-IPSe-BMMDP
ICT-IPSe-BMML	ICT-IPSe-BMMLP
ICT-IPSe-BMM	ICT-IPSe-BMMP
ICT-IPSe-LDM	ICT-IPSe-LDMP
ICT-IPSe	

Date and Revision: May 2026, Revision 1.03

Copyright © 2026 Innovative Circuit Technology Ltd. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of Innovative Circuit Technology Ltd.

Disclaimer

ICT shall not be held liable for any damage or injury involving this product if it has been subjected to misuse and exposure to environmental conditions not conforming to the product's limits of operation, improper installation, or maintenance.

The illustrations in this manual are for illustrative purposes only. Review the drawings before proceeding. If there are questions and concerns regarding the product, refer to the FAQs section or contact ICT.

Contact Information

- North America toll-free: +1 877.930.0717 ext. 810
- International: +1 604.856.6303 ext. 810
- E-mail: techsupport@ictcorporate.com

ICT LIMITED WARRANTY

The warranty period on ICT products is two (2) years from date of purchase from an authorized ICT reseller or OEM with valid proof of purchase, or from date of shipment from the ICT manufacturing facility. The warranty period for a repaired product or part is ninety (90) days or the remainder of the unexpired term of the new product warranty period, whichever is greater. Repair or replacement of a defective product or part does not extend the original warranty coverage period.

The ICT Limited Warranty is only intended for the benefit of the original purchaser and user of this product. This Warranty is not transferable or assignable without the prior written permission of ICT. ICT's sole obligation and liability under this warranty is limited to either repairing or replacing defective products at the sole discretion of ICT. When repairing or replacing the products, ICT may use products or parts that are new, equivalent to new or re-conditioned. Parts repaired or replaced during the warranty period will be under warranty for the remainder of the warranty period.

No claim will be accepted unless written notice of the claim is received by ICT in accordance with ICT's Return Material Authorization (RMA) procedure, as soon as reasonably possible after the defect is discovered. A valid product serial number must be provided with the RMA claim to prove eligibility. The RMA procedure is available on the ICT website at www.ict-power.com/support/warranty-repair/.

The Purchaser shall at their own risk and cost return the defective product to ICT's factory or designated repair center once an RMA is issued by ICT. Return of the products to the customer after repair is completed shall be prepaid by ICT unless otherwise mutually agreed between the parties. Products shipped to ICT which have incurred freight damage will not be covered by this Warranty and any repairs or replacement parts, components or products needed will be invoiced in the full current price amount and returned freight collect to the Purchaser. It is the Purchaser's responsibility to check the product upon receipt for any damage during shipping and to contact the carrier or shipper regarding such damage. Product that is returned as defective, which is determined to operate within published specifications will be returned to the Purchaser freight collect.

ICT assigns to the Purchaser any warranties which are made by manufacturers and suppliers of components of, or accessories for, the ICT product and which are assignable. ICT makes no representations as to the effectiveness or extent of such warranties, assumes no responsibility for any matters which may be warranted by such manufacturers or suppliers and extends no additional coverage under this Warranty to such components or accessories.

In no event shall ICT be liable for any special, indirect, or consequential damages such as, but not limited to, loss of use, business or goodwill, loss of revenue, or loss of profits, which may result, either directly or indirectly, from defects in products provided by ICT.

This Warranty will be void if the product has been subjected to misuse, neglect, accident, exposure to environmental conditions not conforming to the products' limits of operation, improper installation or maintenance, improper use of an electrical source, defects caused by sharp items or by impact pressure, a force majeure event, has been modified or repaired by anyone other than ICT or its authorized representative, has been subjected to unreasonable physical, thermal or electrical stress, improper maintenance, or causes external to the unit including but not limited to general environmental conditions such as rust, corrosive atmospheres, sustained temperatures outside the specified operating range of the equipment, exposure to power surges and/or electrical surges, improper grounding, mold or dust, animal or insect damage, water damage or immersion in liquid of any kind, or if the serial number has been altered, defaced, or removed.

ICT does not control the installation and use of any ICT product. Accordingly, it is understood this does not constitute a warranty of performance or a warranty of fitness for a particular purpose. This Warranty represents the entire agreement between ICT and Purchaser with respect to the subject matter herein and supersedes all prior verbal or written communications, representations, understandings, or agreements relating to this subject.

Return Material Authorization Procedure

1. Request RMA number from ICT through telephone, e-mail, or website from Monday to Friday between 8:00am and 4:30pm Pacific Time.
 - North America toll-free: +1 877.930.0717 ext. 810
 - International: +1 604.856.6303 ext. 810
 - E-mail: techsupport@ictcorporate.com
 - ICT website: <https://ict-power.com/support/warranty-repair>
2. Provide the following information when requesting an RMA:
 - ICT model number
 - Serial number
 - Return ship-to address
 - The preferred shipping courier and account number, if applicable
 - An estimate of what the possible failure cause might be

TABLE OF CONTENTS

1.0 INTRODUCTION	1
1.1 System Components and Features	1
1.1.1 Intelligent Control Module (ICM)	2
1.1.2 Power Module	2
1.1.3 Battery Management Module (BMM or BMMD)	2
1.1.4 Load Distribution Module (LDM)	3
1.1.5 Power Shelf.....	3
2.0 INSTALLATION	3
2.1 Unpacking and Inspection.....	3
2.2 Package Contents.....	4
2.2.1 Tools and Parts Needed	4
2.3 Quick Install Guide.....	4
2.4 System Configuration.....	5
2.5 Rack Mounting.....	7
2.6 Ground Connection.....	7
2.7 Surge Protection Device(s) Installation	8
2.8 Sensor and Alarm Connections	8
2.9 Battery Connections.....	10
2.10 Installation of the Breakers (if applicable).....	20
2.11 Installation of the Power Modules	21
2.12 Network Cable Connection.....	22
2.13 AC Power Source Connections	22
2.14 Software Configuration	23
2.15 Load Connections	23
2.16 System Wiring Final Verification	26
2.17 Energize Loads and Battery Connections	27
3.0 OPERATION: FRONT DISPLAY PANEL	28
3.1 Graphic Display	28
3.2 Menu Structure.....	28
3.2.1 System Status.....	31
3.2.2 Battery Management Module (if installed).....	32
3.2.3 Load Distribution Module (if installed)	44
3.2.4 Alarm Inputs	45
3.2.5 Alarm History.....	46
3.2.6 Network Status and Advanced Options.....	46
3.2.7 Notification Screens	50
3.3 Password Reset	51
3.3.1 LCD Password Reset.....	51
3.3.2 GUI Password Reset	51
3.3.3 User Password Reset	52
3.4 Status Indicators and Alarms.....	52

4.0 OPERATION: GRAPHICAL USER INTERFACE	55
4.1 Log In/Log Out.....	55
4.2 System	56
4.2.1 STATUS	57
4.2.2 SETTINGS & CONTROL	59
4.3 Power Modules.....	61
4.3.1 STATUS	61
4.3.2 SETTINGS & CONTROL	62
4.4 Battery Backup (if installed).....	63
4.4.1 STATUS	63
4.4.2 SETTINGS & CONTROL	66
4.5 Load Distribution (if installed)	77
4.5.1 STATUS	77
4.5.2 SETTINGS & CONTROL	78
4.6 Alarms	83
4.6.1 STATUS	83
4.6.2 SETTINGS & CONTROL	83
4.7 Communications.....	84
4.7.1 BASIC SETUP	84
4.7.2 NETWORK SETUP	88
4.7.3 E-MAIL SETUP	93
4.7.4 USER SETUP	95
4.7.5 MAINTENANCE	98
4.8 Help.....	103
5.0 OPERATION: PARALLEL (Not applicable)	103
6.0 OPERATION: STANDARD POWER SHELF (Not applicable)	103
7.0 FAQs	104
8.0 PRODUCT SPECIFICATIONS	107
8.1 Electrical Specifications	107
8.2 Physical Specifications	109
8.3 Regulatory Specifications	110
8.4 Mechanical Specifications.....	110
9.0 GLOSSARY	112

LIST OF FIGURES

Figure 1. A Typical Modular Power Series 2 Configuration.....	2
Figure 2. Typical Rear View	7
Figure 3. The BMM.....	12
Figure 4. The BMMDP	12
Figure 5. Location of RS-485 Modbus Connector	13
Figure 6. RJ-45 Port.....	14
Figure 7. Daisy-Chain RS-485 Battery Connections	14

Figure 8. Custom Cable Pinout for Narada and Power Storage Solutions Batteries	15
Figure 9. Custom Cable Pinout for EG4 and Cyclone Batteries	15
Figure 10. Straight-Through Cable Pinout for Narada and Power Storage Solutions Batteries	15
Figure 11. Straight-Through Cable Pinout for EG4 and Cyclone Batteries	16
Figure 12. Communication Connectors	19
Figure 13. Installing Breaker with Even Pressure	20
Figure 14. Circuit Breaker Removal Using an Appropriate Tool	20
Figure 15. Installing Power Module in a Unit	21
Figure 16. The DC Output Bus Bars	24
Figure 17. The LDM	25
Figure 18. The LDMP	25
Figure 19. Connecting the Load Wires	26
Figure 20. Installation of the Bus Bar Cover	27
Figure 21. ICM Front Control Interface	28
Figure 22. ICM Menu Structure (cont'd on next page)	29
Figure 23. ICM Menu Structure (cont'd from previous page)	30
Figure 24. Module Number Identification	102
Figure 25. Dimensions	111

LIST OF TABLES

Table 1. Power Module Ratings	1
Table 2. Power Shelf Models (cont'd on next page)	5
Table 3. Power Module Models	6
Table 4. Available Accessories	6
Table 5. Minimum Size Equipment Grounding Conductors for Grounding Raceway and Equipment	8
Table 6. Alarm Output Connector	9
Table 7. Remote Input Connector	9
Table 8. Default System Output Settings	11
Table 9. Available BMM Models (cont'd on next page)	12
Table 10. Supported Battery Models	13
Table 11. Narada DIP Switch Configuration	16
Table 12. Power Storage Solutions DIP Switch Configuration (cont'd on next page)	16
Table 13. EG4 LL DIP Switch Configuration (cont'd on next page)	17
Table 14. Cyclone DIP Switch Configuration	19
Table 15. AC Source Wiring Connections	23
Table 16. Recommended Breaker Rating	23
Table 17. Load Connection Points	24
Table 18. LDM Output Capacity	25
Table 19. List of Battery Types	35
Table 20. Power Module Alarms	53
Table 21. Battery Management Module (BMM) Alarms	54
Table 22. Load Distribution Module (LDM) Alarms	54

Table 23. Intelligent Control Module (ICM) Alarms	55
Table 24. List of Battery Types	67
Table 25. Default Equalize Voltage Settings	70
Table 26. Deeply Discharged Battery Values (typical)	72
Table 27. Default Disconnect Voltage Settings	72
Table 28. Default Reconnect Voltage Settings.....	72
Table 29. The Minimum Difference Between Disconnect and Reconnect Voltage	72
Table 30. Default Discharge Voltage Limit Settings	75
Table 31. Overall Electrical Specifications	107
Table 32. Power Module Specifications (cont'd on next page)	107
Table 33. Battery Management Module Specifications	108
Table 34. Load Distribution Module Specifications	109
Table 35. Physical Specifications	109
Table 36. Heat Dissipation.....	110
Table 37. Regulatory Compliance.....	110
Table 38. Dimension and Weight.....	110

1.0 INTRODUCTION

The Modular Power Series 2 is a flexible, N+1 redundant DC power system with intelligent networked control, advanced battery management, and managed load distribution options in a pre-configured 1RU rack mount chassis. The main power shelf features a factory-installed Intelligent Control Module (ICM) with front graphic display and up to four parallel-connected hot-swappable 700-, 1,000-, or 1,500-watt, 12-, 24- or 48-volt Power Modules, for a potential maximum of 6,000 watts or 162 amps continuous output rating.

Alternatively, the two right-hand slots may be used for a factory-installed Battery Management Module (BMM) with Low Voltage Disconnect (LVD) contactor, one or two 100-amps circuit breakers, battery current monitor, and advanced battery state-of-charge estimation and discharge test capability; and an intelligent four-channel Load Distribution Module (LDM) to provide four 25-amp breaker-protected outputs with advanced monitoring and remote on/off control.

Table 1. Power Module Ratings

Module	Output Voltage adjustment range (V)	Default Output Voltage (V)	Output Current Limit adjustment range (A)	Default Current Limit (A) (+5%, -0%)
12 V 50 A ICT700-12PM	11.5–15.5	13.8	10–50	50
24 V 25 A ICT700-24PM	23–31	27.6	5–25	25
48 V 18 A ICT1000-48PM	46–60	55.2	3–20	18
24 V 54 A ICT1500-24PM	23–31	27.6	5–54	54
48 V 27 A ICT1500-48PM	46–62	55.2	3–27	27

1.1 System Components and Features

A typical configuration is illustrated in Figure 1. This unit consists of a power shelf with an ICM, two 700-, 1,000- or 1,500-watt Power Modules, a dual input Battery Management Module (BMMD), and a Load Distribution Module (LDM) with output breakers. This single 1RU shelf provides a remotely managed 1,400 watts, 2,000 watts, or 3,000 watts of hot-swappable DC power with built-in battery breakers, Low Voltage Disconnect (LVD), advanced battery management, and four channels of intelligent, remotely controlled DC power distribution.




Figure 1. A Typical Modular Power Series 2 Configuration

1.1.1 Intelligent Control Module (ICM)

- OLED display with intelligent front panel controls fully integrated into power shelf
- 10/100/1000 Base-T Ethernet communications port
- Embedded web server with easy-to-use graphical user interface (GUI)
- Intelligent monitoring, reporting and control of system and all installed modules
- RS-485 Battery Monitoring Support for BMS integration over Modbus
- HTTPS, SMTP, SNMP (v1, v2c, v3) protocols supported
- Alarm notifications via front panel display, GUI, e-mail, text, and SNMP
- Four digital site monitoring sensor inputs with alarm reporting
- Event data logging
- Password protection and HTTPS security

1.1.2 Power Module

- 100–300 VAC input with power factor correction
- 700-, 1,000- or 1,500-watt hot-swappable Power Modules
- 12-, 24- or 48-volt nominal DC output (floating ground)
- Up to 95% efficiency
- –30 to +60°C operating temperature range
- Power Saving mode available with 1,000-watt Power Modules

1.1.3 Battery Management Module (BMM or BMMD)

- Single or dual 100-amp battery disconnect circuit breakers
- Optional 100-amp output circuit breaker
- Integrated 150-amp low voltage disconnect
- Advanced battery management features (with ICM installed) including:
 - temperature compensated charging (lead-acid batteries only)



- display of battery voltage
- battery status
- battery current
- state of charge
- run time remaining
- adjustable LVD settings
- configurable advanced battery management features such as boost charge parameters, maximum charge current, battery capacity, battery test timer, and battery discharge test cutoff voltage
- Support for lead-acid and lithium-ion battery types (features differ depending on battery type)

1.1.4 Load Distribution Module (LDM)

- TCP/IP remote management and power control of individual outputs (with ICM installed)
- Four fully managed load outputs with individual power cycling for each output
- Adjustable alarm and load-shed settings for each output
- Monitoring and alarm reporting of each output
- Supports 10–24AWG load wires

1.1.5 Power Shelf

- Power shelf with optional fully integrated Intelligent Control Module provides remote monitoring and control of DC power system over Ethernet
- Hot-swappable 700-, 1,000 or 1,500-watt, 12-, 24- or 48-volt DC high efficiency Power Modules
- Accommodates optional factory-installed Battery Management Module and Load Distribution Module in 1RU space
- Flexible configurations allow the DC power system to be matched to the requirement

2.0 INSTALLATION

The following is the recommended sequence for the installation process.

2.1 Unpacking and Inspection

Perform a physical check of the unit as it is being taken out of the box to ensure it has not been damaged during shipping. Check that the system configuration matches the version ordered, and that the accessories under the package contents section were shipped with the unit.

NOTE: In case of shipping damage, your freight carrier should be notified immediately.

2.2 Package Contents

- Quick Start Guide
- Power shelf (hot-swappable Power Modules must be ordered separately)
- Two rack-mounting ears (installed)
- One nut on the ground stud (installed)
- Bag containing the following:
 - Instruction manual (USB drive)
 - One 3-pin AC input wire clamp connector
 - One 7-pin alarm and temperature sensor wire clamp connector
 - One 3-pin form-C alarm relay connector
 - Two 6-32 x 1/4-inch screws for installing the safety cover
 - Two 1/4-inch bolt/washer/nut sets for DC output bus bar connection
 - Two 1/4-inch bolt/washer/nut sets for the BMM bus bar connection (included when BMM is installed in the shelf)
 - Remote battery temperature sensor (ICT-TMP) (included when a BMM or BMMD is installed in the system)
 - Output bus bar safety cover
 - Clamp adhesive for mounting the ICT-TMP

2.2.1 Tools and Parts Needed

- Two 7/16-inch wrenches
- Wire stripper and crimper
- Four screws to install the unit into the equipment rack
- #1 Phillips screwdriver for the connections of rack ears, output bus bar cover, and AC input connector
- 3/32-inch flathead screwdriver for the connections of the AC input wires, alarm and sensor wires, and for the LDM connections
- Pliers to remove circuit breakers

2.3 Quick Install Guide

- Unpack and check that the unit and all materials have been delivered.
- Obtain the recommended tools.
- Check and verify the configuration.
- Mount the unit into a 19-inch rack.
- Connect the chassis ground according to the site design and in accordance with local electrical code standards.
- Connect the sensors and alarms.
- Connect the battery.
- Connect the BMS (Battery Management System) cable (if required).
- Insert the breakers and Power Modules.

- Connect the network cable using third-party surge protection.
- Connect and energize the AC power source, using third-party surge protection.
- Configure the software settings.
- De-energize the unit and connect the load devices using third-party surge protection on all DC conductors which may be exposed to environmental factors such as lightning.
- Verify the system wiring.
- Energize the loads and battery connections.

2.4 System Configuration



CAUTION

Risk of personal injury or damage to equipment and property. Always observe the following:

- Ensure the unit has the correct polarity for the application (see Table 2).
- Do not combine 12-volt, 24-volt, and 48-volt Power Modules within the same unit.
- Ensure that there are enough matching Power Modules available to support the load requirement including N+1 redundancy if required.

NOTE: Power Modules and accessories must be ordered separately.

Table 2. Power Shelf Models (cont'd on next page)

Description	Model No. (negative V output)	Model No. (positive V output)
Intelligent Power Shelf with Control Module, up to 174 A output max	ICT-IPSe	ICT-IPSe
Intelligent Power Shelf with Control Module and a single 100 A input Battery Management Module	ICT-IPSe-BMM	ICT-IPSe-BMMP
Intelligent Power Shelf with Control Module and a single 100 A input Battery Management Module, and Load Distribution Module with 4 x 25 A (cont.) outputs	ICT-IPSe-BMM-LDM	ICT-IPSe-BMM-LDMP
Intelligent Power Shelf with Control Module and Load Distribution Module with 4 x 25 A (con.) outputs	ICT-IPSe-LDM	ICT-IPSe-LDMP
Intelligent Power Shelf with Control Module and two Load Distribution Modules with 8 x 25 A (cont.) outputs	ICT-IPSe-LDM-LDM	ICT-IPSe-LDM-LDMP

Description	Model No. (negative V output)	Model No. (positive V output)
Intelligent Power Shelf with Control Module, and a dual 100 A Battery Management Module (dual matching battery strings combined through single LVD and current monitor)	ICT-IPSe-BMMD	ICT-IPSe-BMMDP
Intelligent Power Shelf with Control Module and a dual 100 A Battery Management Module, and Load Distribution Module with 4 x 25 A (max.) outputs	ICT-IPSe-BMMD-LDM	ICT-IPSe-BMMD-LDMP
Intelligent Power Shelf with Control Module, and a single 100 A input, 100 A load output Battery Management Module	ICT-IPSe-BMML	ICT-IPSe-BMMLP

Table 3. Power Module Models

Description	Model No.
12 V, 700 W Power Module (13.8 V, 50 A)	ICT700-12PM
24 V, 700 W Power Module (27.6 V, 25 A)	ICT700-24PM
48 V, 1,000 W Power Module (55.2 V, 18 A)	ICT1000-48PM
24 V, 1,500 W Power Module (27.6 V, 54 A @ 230 VAC)	ICT1500-24PM
48 V, 1,500 W Power Module (55.2 V, 27 A @ 230 VAC)	ICT1500-48PM

Table 4. Available Accessories

Description	Model No.
5 A circuit breaker for LDM	ICT-CB5
10 A circuit breaker for LDM	ICT-CB10
15 A circuit breaker for LDM	ICT-CB15
25 A circuit breaker for LDM	ICT-CB25
30 A circuit breaker for LDM	ICT-CB30
Blanking plate for unused power module positions (snap-in)	ICT-BPM
Battery temperature sensor (1 pc included with Power System/BMM)	ICT-TMP

2.5 Rack Mounting



- Provide adequate support for the rear of the unit without obstructing the air vents.
- Do not block air inlet or outlet openings, as this could interfere with proper ventilation and performance.

Mount the unit in an enclosed, standard 19-inch equipment rack or other restricted access location, using rack mounting screws (not supplied). Support the rear of the unit with rack shelf supports or back rail if required.

2.6 Ground Connection



De-energize the system before making any change to the wiring and connections.



All DC outputs of ICT's DC power systems are isolated from chassis ground (floating). DC output returns can remain isolated from ground (DC-I) or can be grounded (DC-C), as per site grounding requirements and/or local or national electrical codes. Ensure that all relevant electrical code standards are followed.




Figure 2. Typical Rear View

Connect a ground bonding wire from the chassis ground stud to a nearby common grounding point. Use a ground bonding wire that is sized in accordance with NEC Table 250.122 (see Table 5). Ensure that the selected ground bonding wire is rated to handle the maximum current rating of the power system.

Table 5. Minimum Size Equipment Grounding Conductors for Grounding Raceway and Equipment

Maximum Circuit Breaker Size (Amps)	Conductor Size (AWG or kcmil)	
	Copper	Aluminum or Copper-Clad Aluminum
15	14	12
20	12	10
30	10	8
40	10	8
60	10	8
100	8	6
200	6	4
300	4	2
400	3	1

This is sourced from "National Electrical Code 2005 Edition", p. 70-112.

2.7 Surge Protection Device(s) Installation

Third-party surge protection devices must be utilized to protect AC input power feeds, every exposed DC power conductor and exposed data cables. These protection devices must be installed at both ends of the exposed conductor, in close proximity to installed equipment. Periodically inspect these surge protection devices for proper function.

NOTE: Consult with manufacturers of surge suppression devices to select appropriately rated protection device(s) and proper installation methods.

2.8 Sensor and Alarm Connections

The ALARM and AUX connectors allow the Modular Power Series 2 to monitor external devices and batteries, and to report faults to an external monitoring device through a form-C contact.

NOTE: The Form-C relay provides a voltage-free (dry) contact and does not supply power. It is intended to switch external circuits energized by an external voltage source.

1. If needed, connect form-C contact monitoring wiring to the ALARM connector as shown in Table 6. Use 22–26 AWG wire. Refer to Tables 20–23 for which conditions will trigger a form-C alarm.

NOTE: On a dual-shelf system, the alarm trigger signal is available only on the top shelf. When the ICT-JMP cable is connected, the top shelf alarm contacts are activated for all system alarms, including those originating from the bottom shelf. If the ICT-JMP cable is not connected, only alarms from the top shelf are reported. Ensure that the ICT-JMP cable is connected to enable full system alarm reporting.

Table 6. Alarm Output Connector

Pin Number	Name	Function
1	NC	Alarm NC (alarm state)
2	NO	Alarm NO (alarm state)
3	Common	Alarm output common

2. If needed, connect up to four devices to the AUX connector as shown in Table 7. Use 22–26 AWG wire.
3. Connect the external Battery Temperature Sensor (ICT-TMP) to the AUX connector as shown in Table 7 (use for lead-acid batteries only). This will allow the Modular Power Series 2 to compensate the battery charge voltage according to the battery temperature. Use 22–26 AWG wire.

Table 7. Remote Input Connector

Pin Number	Name	Function
1	Alarm 1	Alarm 1 input
2	Alarm 2	Alarm 2 input
3	Alarm 3	Alarm 3 input
4	Alarm 4	Alarm 4 input
5	Alarm Return	Common alarm return
6	Bat Temp	Battery temperature sensor
7	Bat Temp	Battery temperature sensor return

Mount the sensor to the mid-level side of the middle battery in a battery bank using the adhesive-backed clip. The rate of voltage compensation (with optional BMM or BMMD installed) can be adjusted through the ICM front display panel interface, or the Graphical User Interface (GUI) in the Battery Backup Settings section. The default compensation is 0 mV/C per cell (no compensation). Adjust this according to the battery manufacturer's

recommendation to enable charge voltage temperature compensation.

NOTE: Battery temperature is assumed to be 25°C if no sensor is installed.

4. Install wiring to monitor up to four external devices such as smoke, door or water sensors through the digital alarm inputs. Each alarm input can be connected to a form-C/dry contact on the external device. If the alarm state changes on the device being monitored, the GUI will report the alarm. The GUI allows each of the four alarm inputs to be labelled with a unique name (see Section 4.6.2).
5. Enable the alarm inputs and set the contact logic (normally open or normally closed) in the GUI, Alarms Settings & Control tab (see Section 4.6.2).

2.9 Battery Connections



Risk of serious personal injury or damage to equipment and property. Observe the following:

- Use a battery with rating and capacity appropriate for the model of power supply in use.
- Use an appropriate DC overcurrent protection device in line with the backup battery connection.
- Use wire and connectors rated for the maximum load current.
- Ensure battery polarity is correct before connecting.
- Do not attempt to charge a frozen battery.
- Always install batteries in well-ventilated areas.
- Handle batteries with care. Never short-circuit battery terminals.
- Always consult with and observe all battery manufacturer recommendations.
- When connecting a battery, ensure the nominal battery voltage is correct, and that the battery positive is connected to a positive terminal and the battery negative is connected to a negative terminal.
- Note that the BAT terminal on the BMM is internally tied to either the (+) or (-) system output through the LVD contactor, depending on the polarity of the power system used.
- Check system model polarity before connecting a battery to the BMM.



Risk of serious personal injury or damage to equipment and property. Observe the following:



- Only use the Equalize Charge setting for flooded lead-acid batteries in a well-ventilated location. **Do not use Equalize Charge on sealed or lithium-ion batteries.** Always consult with and observe all battery manufacturer recommendations.
- Do not connect either of the unit’s main outputs to the BAT terminal on the BMM, as this may short-circuit the battery or bypass the internal LVD circuitry in the BMM.
- Use wire and connectors appropriately rated for the highest possible system current when making connections to the battery, BMM, and main DC output.
- If a lithium-ion battery is used, it must utilize an integrated battery management system (BMS) to protect the battery cells from inappropriate voltage or current levels.



Leave BMM breaker turned off until the software has been configured (see Section 3.2.2 or Section 4.4.2).

The optional BMM or BMMD dual breaker module provides a convenient and safe way to connect an external lead-acid or lithium-ion backup battery to the Modular Power Series 2. A 100-amp hydraulic-magnetic circuit breaker provides overcurrent protection, while an internal 150-amp LVD contactor will disconnect the battery should it discharge below the voltage level which is set in the Battery Backup section of the GUI. Internal battery current monitoring provides a full suite of remote battery charge monitoring features.

1. Check that the default system output voltage and current limit match the requirements of the battery and the loads to be connected. Adjust the system Output Voltage and Current Limit (see Section 3.2.1 or Section 4.2.2) to match the combined battery and system load requirements before making final connections, if required.

Table 8. Default System Output Settings

Output Settings	ICT700-12PM	ICT700-24PM	ICT1000-48PM	ICT1500-24PM	ICT1500-48PM
Output Voltage	13.8 V	27.6 V	55.2 V	27.6 V	55.2 V
Current Limit	464 A	464 A	232 A	464 A	232 A

NOTE: Use only identically rated battery strings for the dual battery BMMD option to ensure equal charging of each battery set.

- Verify the polarity of the BMM installed in the unit by noting the label under the rear BMM BAT bus bar input. The "BAT +" indicates a positive battery voltage system with the LVD contactor and battery breaker internally connecting this terminal to the shelf "+" output, while the "BAT -" indicates a negative battery voltage system, with the LVD contactor and battery breaker internally connecting this terminal to the shelf "-" output (see Figure 3 and Figure 4).




Figure 3. The BMM




Figure 4. The BMMDP

NOTE: Use wire and connectors appropriately rated for the highest possible system current when making connections to the battery, BMMD, and power shelf.

- Connect the battery hot lead (see comment on polarity above) to the BMM BAT bus bar, and the battery return lead to the main shelf output bus bar of the corresponding polarity (i.e., a positive voltage system will have the battery (+) tied to the BMM terminal, with the battery (-) tied to the main NEG output busbar; a negative voltage system will have the battery (-) tied to the BMM terminal, with the battery (+) tied to the main POS output busbar). Install an appropriate in-line DC overcurrent protection device, such as a fuse or circuit breaker, on the battery hot lead. Leave battery breaker open until the software has been configured.

Table 9. Available BMM Models (cont'd on next page)

-V BAT	+V BAT	Description	Connections
BMM	BMMP	Single 100 A battery circuit breaker with LVD contactor with advanced battery management capability	Single BAT input bus bar (+ or - polarity)
BMMD	BMMDP	Dual 100 A battery breakers to connect two identical battery strings through an LVD and current sensor with advanced battery management capability for the combined battery	BAT 1 and BAT 2 input bus bars (both either + or - polarity)

-V BAT	+V BAT	Description	Connections
BMML	BMMLP	Single 100 A battery breaker with LVD contactor with advanced battery management capability, and a 100 A Load output breaker for high current DC output connections	Single BAT input, and load output bus bars (both either + or - polarity)

The MPS 2 provides an RS-485 connection using MODBUS data communications protocol, allowing users to connect supported lithium-ion batteries to the DC power system, which provides reporting of battery metrics and alarms via the DC power system’s Graphical User Interface and SNMP interfaces.




Figure 5. Location of RS-485 Modbus Connector

To connect to the battery, a battery monitoring cable must be assembled using a twisted-pair cable (e.g., CAT5) and two RJ-45 connectors. The cable must be configured based on the battery make and model. Refer to Figure 6 for the connector pinout.

Table 10. Supported Battery Models

Manufacturer	Model
Narada	48NPFC50
Narada	48NPFC100
Narada	48NPFC200
Power Stage Solutions	SCLFP48100 3U
EG4	EG4-LL
Cyclone	CYG-B48V-100A




Figure 6. RJ-45 Port

Up to four batteries can be connected to the MPS Ultra 2 RS-485 port using a daisy-chain configuration. The connection between the MPS Ultra 2 power system and Battery #1 must follow the custom cable pinout specified in Figure 8 or Figure 9. Connections between subsequent batteries should use a straight-through cable pinout, as illustrated in Figure 10 and Figure 11 (standard Ethernet cable).




Figure 7. Daisy-Chained RS-485 Battery Connections




Figure 8. Custom Cable Pinout for Narada and Power Storage Solutions Batteries




Figure 9. Custom Cable Pinout for EG4 and Cyclone Batteries




Figure 10. Straight-Through Cable Pinout for Narada and Power Storage Solutions Batteries




Figure 11. Straight-Through Cable Pinout for EG4 and Cyclone Batteries

Each battery connected to the MPS Ultra 2 must be configured with a unique bus address by setting the Address DIP switches on the battery. The DIP switch operation is specific to each battery manufacturer. The bus address of each battery must be entered in the "BMS RS-485 Setup" of the MPS Ultra 2 (See Section 3.2.2)

Table 11. Narada DIP Switch Configuration

Bus Address	DIP Switch Position					
	#1	#2	#3	#4	#5	#6
39	ON	off	off	off	off	off
40	off	ON	off	off	off	off
41	ON	ON	off	off	off	off
42	off	off	ON	off	off	off
43	ON	off	ON	off	off	off
44	off	ON	ON	off	off	off
45	ON	ON	ON	off	off	off
46	off	off	off	ON	off	off

Table 12. Power Storage Solutions DIP Switch Configuration (cont'd on next page)

Bus Address	DIP Switch Position					
	#1	#2	#3	#4	#5	#6
1	ON	off	off	off	off	off
2	off	ON	off	off	off	off
3	ON	ON	off	off	off	off
4	off	off	ON	off	off	off
5	ON	off	ON	off	off	off
6	off	ON	ON	off	off	off
7	ON	ON	ON	off	off	off
8	off	off	off	ON	off	off

Bus Address	DIP Switch Position					
	#1	#2	#3	#4	#5	#6
9	ON	off	off	ON	off	off
10	off	ON	off	ON	off	off
11	ON	ON	off	ON	off	off
12	off	off	ON	ON	off	off
13	ON	off	ON	ON	off	off
14	off	ON	ON	ON	off	off
15	ON	ON	ON	ON	off	off

Table 13. EG4 LL DIP Switch Configuration (cont'd on next page)

Bus Address	DIP Switch Position					
	#1	#2	#3	#4	#5	#6
1	off	ON	ON	ON	ON	ON
2	ON	off	ON	ON	ON	ON
3	off	off	ON	ON	ON	ON
4	ON	ON	off	ON	ON	ON
5	off	ON	off	ON	ON	ON
6	ON	off	off	ON	ON	ON
7	off	off	off	ON	ON	ON
8	ON	ON	ON	off	ON	ON
9	off	ON	ON	off	ON	ON
10	ON	off	ON	off	ON	ON
11	off	off	ON	off	ON	ON
12	ON	ON	off	off	ON	ON
13	off	ON	off	off	ON	ON
14	ON	off	off	off	ON	ON
15	off	off	off	off	ON	ON
16	ON	ON	ON	ON	off	ON
17	off	ON	ON	ON	off	ON
18	ON	off	ON	ON	off	ON
19	off	off	ON	ON	off	ON
20	ON	ON	off	ON	off	ON
21	off	ON	off	ON	off	ON
22	ON	off	off	ON	off	ON
23	off	off	off	ON	off	ON
24	ON	ON	ON	off	off	ON
25	off	ON	ON	off	off	ON
26	ON	off	ON	off	off	ON
27	off	off	ON	off	off	ON

Bus Address	DIP Switch Position					
	#1	#2	#3	#4	#5	#6
28	ON	ON	off	off	off	ON
29	off	ON	off	off	off	ON
30	ON	off	off	off	off	ON
31	off	off	off	off	off	ON
32	ON	ON	ON	ON	ON	off
33	off	ON	ON	ON	ON	off
34	ON	off	ON	ON	ON	off
35	off	off	ON	ON	ON	off
36	ON	ON	off	ON	ON	off
37	off	ON	off	ON	ON	off
38	ON	off	off	ON	ON	off
39	off	off	off	ON	ON	off
40	ON	ON	ON	off	ON	off
41	off	ON	ON	off	ON	off
42	ON	off	ON	off	ON	off
43	off	off	ON	off	ON	off
44	ON	ON	off	off	ON	off
45	off	ON	off	off	ON	off
46	ON	off	off	off	ON	off
47	off	off	off	off	ON	off
48	ON	ON	ON	ON	off	off
49	off	ON	ON	ON	off	off
50	ON	off	ON	ON	off	off
51	off	off	ON	ON	off	off
52	ON	ON	off	ON	off	off
53	off	ON	off	ON	off	off
54	ON	off	off	ON	off	off
55	off	off	off	ON	off	off
56	ON	ON	ON	off	off	off
57	off	ON	ON	off	off	off
58	ON	off	ON	off	off	off
59	off	off	ON	off	off	off
60	ON	ON	off	off	off	off
61	off	ON	off	off	off	off
62	ON	off	off	off	off	off
63	off	off	off	off	off	off
64	ON	ON	ON	ON	ON	ON

Table 14. Cyclone DIP Switch Configuration

Bus Address	DIP Switch Position					
	#1	#2	#3	#4	#5	#6
39	ON	off	off	off	off	off
40	off	ON	off	off	off	off
41	ON	ON	off	off	off	off
42	off	off	ON	off	off	off
43	ON	off	ON	off	off	off
44	off	ON	ON	off	off	off
45	ON	ON	ON	off	off	off
46	off	off	off	ON	off	off
47	ON	off	off	ON	off	off
48	off	ON	off	ON	off	off
49	ON	ON	off	ON	off	off
50	off	off	ON	ON	off	off
51	ON	off	ON	ON	off	off
52	off	ON	ON	ON	off	off
53	ON	ON	ON	ON	off	off

NOTE: Refer to the Lithium-Ion battery datasheet and specifications for the latest corresponding pin descriptions on the battery RS-485 terminal.

4. Connect the RS-485 cable to the RJ-45 port (lower) on the rear panel.




Figure 12. Communication Connectors

5. Connect the RS-485 end of the cable to the RS-485 port on the battery to allow communication with the BMS controller.

2.10 Installation of the Breakers (if applicable)

Install breakers in the four front locations of the optional LDM by inserting into the four breaker openings ("On" or "I" facing up, "Off" or "0" facing down), ensuring the breaker connector tabs securely seat in the LDM breaker sockets. Leave the breakers turned off until the software has been configured (see Section 3.2.3 or Section 4.5.2).



If the breakers are not fully installed or are not installed "square" they may cause intermittent power loss or unexpected behavior for the load devices.

When installing load breakers, apply even pressure to the top and bottom of the breaker to ensure proper engagement of the breaker with the rear contacts (see Figure 13).




Figure 13. Installing Breaker with Even Pressure

To remove the breakers, use pliers to grasp the guard on one side of the breaker (as shown in Figure 14) and pull straight out.



Do not use screwdriver or similar tool to pry the breaker out, as this may cause damage to the breaker or LDM.




Figure 14. Circuit Breaker Removal Using an Appropriate Tool

2.11 Installation of the Power Modules

Risk of personal injury or damage to equipment and property. Always observe the following:

- Ensure the unit has the correct polarity for the application (see Table 2).
- Do not combine 12-volt, 24-volt, and 48-volt Power Modules within the same unit.
- Ensure that there are enough matching Power Modules available to support the load requirement including N+1 redundancy if required.
- Ensure that the orientation of the Power Module is correct when inserting into the desired slot — the handle and latch should be on the left side facing the Power Module.




Figure 15. Installing Power Module in a Unit

1. Install one to four matching hot-swappable Power Modules — with the same voltage rating — in any remaining open shelf positions. The Power Modules will share the total output load, automatically disconnecting from the internal power bus in the event of an internal failure and may be "hot-swapped" (can be inserted or removed while the system is powered). If "N+1" redundancy is needed, ensure the combined power rating of the installed Power Modules exceeds the total requirement of the planned load by at least 700 watts (1,000 watts or 1,500 watts if using ICT 1,000- or 1500-watt Power Modules).

NOTE: N+1 operation requires excess Power Module capacity to ensure that the load can be fully powered, even if one Power Module should fail or be removed.

2. Carefully align each Power Module with the internal shelf guides.
3. Firmly push into the shelf back plane until the module latch clicks, and the module is flush with the unit's front panel.

NOTE: The Power Modules can be easily removed by pressing the release latch to the right while firmly pulling the module from the unit (the shelf may remain powered while swapping modules). The latch is located under the module handle (see Figure 15).

4. Install an optional blanking plate (ICT-BPM) into any unused Power Module positions to prevent accidental access to the internal circuitry of the system.

2.12 Network Cable Connection

Connect a 10/100/1000Base-T, 4-pair Ethernet cable, using third-party surge protection, to the RJ45 LAN port (upper) on the rear panel to allow for remote monitoring and control of the unit.

NOTE: See the Network Monitoring and Control section for information on configuring and using the built in GUI, e-mail, or SNMP functions (Section 4.7.2).

2.13 AC Power Source Connections



AC input wiring to the Modular Power Series 2 unit must be protected using an outlet with a branch rated circuit breaker of 50 amps or less.



Install appropriately rated surge suppression systems on AC, DC, and data connections.

The ICT Modular Power Series 2 provides flexible, managed DC power from single-phase AC power between 100 and 300 volts AC.

1. Create an AC power cable using a 3-conductor cord rated for the maximum input current of the unit (up to 44 amps) by stripping and terminating the three wires in the Line, Neutral, and Ground terminals of the removable AC input connector provided with the



unit (AC line labeled "L", neutral labeled "N" and safety ground labeled "≡").

Table 15. AC Source Wiring Connections

AC Voltage	3-Conductor Cord	Connection to ICT Unit
120/240 VAC (Single-Phase)	Line Neutral Ground	Line to Line Neutral to Neutral Ground to Ground
240 VAC (Split-Phase/Two-Phase)	Line1 Line 2 Ground	Line 1 to Line Line 2 to Neutral Ground to Ground

2. De-energize the AC source by switching off its circuit breaker.
3. Plug the AC connector into the AC input on the unit rear panel and tighten the captive retaining screws.
4. Connect the source end of the cord to the de-energized AC source equipped with a third-party surge protection and a branch rated circuit breaker as shown in Table 16.
5. Energize the AC feed.

Table 16. Recommended Breaker Rating

System Power Module Capacity	Recommended Breaker Rating
2 Power Modules	30 A
3 Power Modules	40 A
4 Power Modules	50 A

2.14 Software Configuration

Configure the software (see Section 3 or Section 4).

2.15 Load Connections



Damage to the unit, load, and/or personal injury may occur if the battery current through the BAT terminal exceeds 150 amps.



Risk of personal injury or damage to equipment and property. Always observe the following:

- DC-AC inverters should not be connected to any of the load connection points without a battery connected to the system. DC-AC inverters create significant inrush current and may damage the circuitry or interfere with the operation of power supplies when there is no battery connected. Connecting a DC-AC inverter in this way may void the product warranty.
- Do not connect DC-AC inverters to the outputs of the Load Distribution Module of the ICT units.
- Install appropriately rated surge suppression systems on AC, DC, and data connections.

1. De-energize the unit before making or changing any connections.
2. Make connections to the load using wire and connectors appropriately rated for the maximum load current. The load may be powered in three different ways.

Table 17. Load Connection Points

Load Connection Points	Features
Directly from main shelf DC Output bus bars	Full current rating of the shelf and combined Power Modules are available to operate the load
One of up to four LDM output channel connector ports (optional "LDM" installed)	Channel overcurrent protection with LDM front circuit breaker (1 to 4), individual remote channel on/off control and current monitoring
High current BMM load output bus bar (if optional factory installed BMML module is installed)	Output overcurrent protection with BMM front 100 A load breaker (breaker 2), load current monitoring

If using the DC output bus bars, connect the load "Return" to either the "POS" bus bar for a negative voltage system or "NEG" bus bar for a positive voltage system (see Figure 16). Connect the load output to the other bus bar. Ensure that the software has been configured (see Section 3.2.1 or Section 4.2.2) before connecting the loads to the DC output bus bars.



Figure 16. The DC Output Bus Bars

If using the LDM outputs, an "Output" (labelled + or – depending on polarity) and "Return" (labelled RTN) connection are provided for each channel (see Figure 17 and Figure 18).



Figure 17. The LDM




Figure 18. The LDMP

The LDM provides four remotely controlled and monitored outputs, with front panel overcurrent protection provided by hydraulic-magnetic circuit breakers (see Section 2.10 for the installation instructions for the breakers). The LDM maximum current rating is 100 amps. Each output can accept 25 amps continuous.

Table 18. LDM Output Capacity

System Voltage	LDM Output Capacity
12, 24, or 48 V	Up to 4 x 25 A

NOTE: Due to the breaker-detection circuitry internal to the unit, it may be possible to measure a voltage on the terminal(s) with no load connected, even if that terminal's breaker is open circuit. This is normal operation. The breaker-detection circuitry is a high-impedance circuit, and while a voltage may be present on the output terminal, it is a signal voltage and does not support loading. A load device connected to the output will immediately pull this voltage to zero volts.

Risk of personal injury or damage to equipment and property. Always observe the following:

- Ensure that the combined current draw on all four LDM outputs does not exceed the output capacity of the Power Modules, or 100 amps, whichever is less.
- Leave breakers turned off until the software has been configured (see Section 3.2.3 or Section 4.5.2).
- Do not connect DC-AC inverters to the outputs of the Load Distribution Module of the ICT units.



1. Ensure that the unit is de-energized before making or changing any connections.
2. Locate the four controlled outputs on the LDM rear panel connector block.

NOTE: The internal channel relay, current sensor and circuit breaker are in the "hot" or output line, with voltage polarity depending on the configuration of the unit (each output = NEG V, for -48 V configured systems, each output = POS V, for +12, +24, or +48 V configured systems).

3. Verify the polarity of the Modular Power Series 2.
4. Connect up to four external loads using appropriately rated wire inserted and secured into the four cage-clamp outputs on the LDM module rear panel. The LDM will accept wires from 10–24 AWG.

Connect the wire by inserting a flathead screwdriver into the upper opening, then insert the wire into the output terminal (lower opening) and release the flathead screwdriver.




Figure 19. Connecting the Load Wires

If using the BMML module, the load "output" connects to the BMML while return connects to the DC Output bus bar.

2.16 System Wiring Final Verification

1. Check that all connections to the power supply are correct and properly tightened.
2. Remove the protective film from the bus bar cover. Align and insert the mounting tabs, then fasten the cover using the supplied screws.




Figure 20. Installation of the Bus Bar Cover

2.17 Energize Loads and Battery Connections

1. Re-energize the AC source to energize the loads.
2. Switch on the optional BMM or BMMD battery breaker 1, and battery breaker 2 (if using) to connect the backup battery string(s) to the system.
3. Switch on the BMML output breaker (if installed) to energize any loads connected to the BMML output.
4. Switch on the LDM output breakers 1 up to 8 (if installed) to energize any loads connected to the Load Distribution Module outputs.

3.0 OPERATION: FRONT DISPLAY PANEL

Switch on the external AC power source circuit breaker; check that the green POWER LED is lit on each Power Module and that the Intelligent Control Module (ICM) front graphic display is lit.

The Modular Power Series 2 will start up and operate at the factory default settings when AC power is connected, generally requiring no other set up or adjustment for basic operation.

3.1 Graphic Display

Use the front display panel and four interface buttons on the ICM to monitor the system status and to make changes to settings such as output voltage, current limit, and battery low voltage disconnect points.




Figure 21. ICM Front Control Interface

NOTE: The display will turn off after approximately 60 minutes of no use and can be re-activated by momentarily pressing any button.

Up/Down ▲▼ Buttons: Use to scroll through display screens, and to adjust selected settings.

Enter ◀ Button: Use to select a screen for adjustment; to save a change and return to the previous screen.

Back X Button: Use to return to previous screen without saving changes.

3.2 Menu Structure

See the complete menu structure in the following diagram. Navigate through the various screens using the four interface buttons.




Figure 22. ICM Menu Structure (cont'd on next page)

NOTE: Connectors (A), (B) and (C) show continuation of the structure from one page to another.





Figure 23. ICM Menu Structure (cont'd from previous page)

NOTE: Connectors (A), (B) and (C) show continuation of the structure from one page to another.



3.2.1 System Status

The main system status screen will show the most current operating conditions for the unit, primarily the Input Voltage (VAC), the Output Voltage (VDC), the total Output Current (A), and a bar graph indicating relative output current.



Other information will be shown depending on the operating state of the unit:

- A small thermometer symbol to indicate that the remote temperature sensor is installed and may be compensating the battery charge voltage
- Indication that the output has been disabled (off)
- Indication that a battery discharge test is in process
- The Input Voltage or Output Voltage will be flashing during an AC voltage or output voltage failure
- The Output Current will be flashing when the unit is operating at the set Current Limit



← Press Enter to move to the System Settings.

System Settings


The Output Voltage and Output Current Limit settings come with factory default values that should be adjusted to match the actual system and battery float voltage requirements, as shown below:



Scroll to highlight the parameter to change.

- System Voltage
- Max total Output Current Limit
- Output Enable ON/OFF (default = ON)
- Advanced Options (see Section 3.2.6)

← Press Enter to select.




Use the Up/Down buttons to adjust setting (Output Voltage shown), press Enter **↵** to set value and return to previous screen. Press Back **X** to return to System Settings screen without saving changes.

NOTE: The output voltage and current limit settings apply to the combined output of all installed Power Modules. The ICM treats the combined modules as a single high-power supply. Adjust the system Output Voltage and Current Limit (see System Settings section) to match the battery type and system load requirements if required.

3.2.2 Battery Management Module (if installed)

The BMM Status Screen indicates the Battery Voltage (VDC), the combined Battery Current, the approximate battery State of Charge (%), and a bar graph showing relative magnitude of the total battery current.



The SOC% is estimated by counting the ampere-hours (Ah) flowing into and out of the battery while knowing the nominal rated capacity of the battery. The system resets the SOC to 100% whenever it detects that the battery is at the rated Float Voltage with minimal charge current for at least 8 hours with lead-acid, or 1 hour with lithium batteries. The SOC is only displayed when the unit is running on battery power. If BMS Communication is enabled, this will display the reported SOC from the battery's on-board BMS.

Other information will be shown depending on the operating state of the unit:


- Battery current will be zero when not charging, "+" while charging and "-" while discharging
- A battery graphic marked with X indicates the battery is disconnected



- Optional BMM versions have the status screens shown below:


Dual Battery String BMM

- Battery 1 Voltage
- Battery 2 Voltage
- Combined Battery Current
- Combined SOC%




Battery with Load BMML

- Battery Voltage
- Approximate SOC%
- Battery Current
- Load Current



- LOW indicates a battery is disconnected or over discharged



Press Enter to move to the BMM Settings.

BMM Settings (All Battery Types)

The module comes with factory default settings that should be reconfigured to match the actual battery used in the system.



Always consult battery manufacturer's specifications when selecting battery type. Incorrect battery type setting may damage the battery. If Lithium-Ion type battery is selected, it must utilize an integrated battery management system (BMS) to protect the battery cells from inappropriate voltage or current levels.




Scroll to highlight the parameter or sub-menu to change.

- LVD Disconnect V
- LVD Reconnect V
- Charge Current Limit
- Overcurrent Alarm level



- Battery Type
- Battery Capacity (Ah) rating
- Battery discharge rate (hrs.) used for capacity spec. (typically either 10 or 20 hrs.)



- Low SOC Alarm
- V Temp-co/cell (default = 0, typically = -4 mV/°C)
- Equalize Charge
- Discharge Test




If the battery type is set to a BMS-supported battery, the 3rd screen will change to show:

- BMS RS-485 Setup
- View Battery Status



Press Enter to select the parameter to be changed/adjusted.



Use the Up/Down buttons to adjust settings (SET DISCT VOLTAGE shown), press Enter  to set value and return to previous screen. Press Back **X** to return to BMM Settings screen without saving changes.

DISCT VOLTAGE: Set the battery Low Voltage "Disconnect Voltage" threshold to a level that will protect the battery from excessive discharge. The LVD contactor will open when the battery discharges to this level for at least 3 seconds.

RECON VOLTAGE: Set the "Reconnect Voltage" higher than the disconnect voltage (see Table 29) to prevent the LVD contactor repeatedly cycling on and off. This setting will be used when charging the battery from an external DC source (such as a solar system), otherwise once AC power returns, the LVD contactor will automatically close so that the Power Modules can charge the battery directly.

NOTE: For lead-acid battery, the LVD contactor will not close if the battery is less than 40 volts on a 48-volt system (see Table 26). The unit believes the battery is deeply discharged, and possibly damaged. A deeply discharged battery will not be reconnected as a safety measure. The battery will need to be manually checked for proper function and then manually charged to at least 40 volts (on a 48-volt system) before the LVD will close. Refer to the battery manufacturer's recommendations on how to proceed with a deeply discharged battery. This does not apply to the system when the Lithium setting has been chosen.

CHARGE CURRENT: Set the "Battery Charge Current Limit" to limit the maximum battery charge current provided, while still allowing the full rated current to be drawn from the main output.

OVERCURRENT: Set the "Battery Overcurrent" to receive an alarm notification when the battery discharge or charge current exceeds the set over-current level.

NOTE: Set the threshold to 0 A to disable this alarm (default setting).

BATT TYPE: Configure the "Battery Type" of the battery used in the system (see Table 19).

Table 19. List of Battery Types

Battery Type	Description	BMS-Supported
Lead Acid		no
Lithium (Cyclone)	Cyclone Brand batteries	yes
Lithium (EG4 LL)	EG4 Electronics Brand batteries	yes
Lithium (Narada)	Narada Brand batteries	yes
Lithium (PWRSS)	Power Storage Solutions	yes
Lithium (viaPhoton)	viaPhoton Brand batteries	no
Lithium (Other)		no

If Lithium Ion-type battery is selected, the following battery parameters and settings will be unavailable. These should be available from the integrated BMS.

- Voltage Temperature Coefficient / cell
- Equalize Charge

BATT CAPACITY: Enter the combined battery capacity in Ah so the system can estimate the total battery SOC%.

BATT RATE: Set the battery rate (hrs.). This represents the discharge rate specified by the battery manufacturer to determine the battery capacity (usually will be 20 hr. or 10 hr. rate).

NOTE: Connecting batteries in parallel will increase the total Ah capacity, while connecting batteries in series will increase the voltage with no change to the Ah capacity.

LOW SOC ALARM: Set the "Low SOC Alarm" (%) if desired, to raise an alarm when the battery is nearly discharged.

TEMP-CO/cell (only available for lead-acid batteries): Ensure the Battery Temperature Sensor (ICT-TMP) is installed and connected to the battery case (see Section 2.8) for optimal lead-acid battery charging and best battery life. Set the "Temperature Compensation/°C" level per battery cell to match the recommendation of the battery manufacturer (-4 mV/°C per cell is typical). The numbers are absolute values.


EQUALIZE CHARGE (only available for lead-acid batteries):

Risk of serious personal injury or damage to equipment and property! Always observe the following:


- Equalize charging is intended for flooded lead-acid batteries only and may produce higher than normal levels of hydrogen gas.
- Consult with the battery manufacturer when using SLA batteries.
- **Do not use equalization charging with lithium-ion batteries.**
- Ensure the battery compartment is well ventilated to avoid any risk of explosion.
- Always consult with and observe all battery manufacturer recommendations.



Configure the "Battery Equalize Charge" voltage, duration, and automatic repeat interval if desired when using flooded lead-acid type batteries only. The system will step up the output voltage to the Equalize Voltage for the Equalize Duration time whenever the Equalize Status is set to Enable. The unit's data log (see Section 4.7.1) will record the completion of the equalization charge while a pop-up window will appear on the front display screen (see Section 3.2.7).




← Press Enter to select.




Scroll to highlight parameter in selected sub-menu.

- Voltage
- Duration
- Status

← Press Enter to set to START EQUALIZE CHARGE screen.



Use the Up/Down buttons to select setting, press Enter ← to set selected setting and return to previous screen. Press Back **X** to return to previous screen without saving changes.




Status will show IN PROGRESS when equalize charge is occurring. Press Back **X** to return to the BMM Settings screen.

← Press Enter to set to STOP EQUALIZE CHARGE screen.



Use the Up/Down buttons to select setting, press Enter ← to set selected setting and return to previous screen. Press Back **X** to return to previous screen without saving changes.




Status will show COMPLETE when equalize charge is completed. Press Back **X** to return to the BMM Settings screen. Press Enter ← to set status to READY.

NOTE: System will state that Manual Equalize Charge is Not Ready if battery is not fully charged (a fully charged battery will have charge current close to zero amps).


DISCHARGE TEST: Configure the "Battery Discharge Test" to check on the battery's ability to power the system for a set duration. Set Max Discharge Time, minimum Stop Voltage, Max Discharge Limit, and the automatic repeat interval if desired. Each time the test is run the output voltage from the Power Modules will be reduced so that the external battery will power the system load until the MAX TIME limit, STOP VOLTAGE, or MAX DISCHARGE limit is reached.

A Discharge Test Complete notification (on the front display and with an e-mail if messaging is configured via the GUI) will indicate a Test Failure if the Stop Voltage is reached before the Max Time limit, as the battery was not able to power the load for the desired duration. The unit's data log (see Section 4.7.1) will record the completion of the discharge test while a pop-up window will appear on the front display screen (see Section 3.2.7).



← Press Enter to select.

Scroll to highlight parameter in selected sub-menu.



- Max Time
- Stop Voltage
- Max Discharge
- Status

← Press Enter to set to START DISCHARGE TEST screen.



Use the Up/Down buttons to select setting, press Enter ← to set selected setting and return to previous screen. Press Back X to return to previous screen without saving changes.

← Press Enter to start discharge test.




Status will show IN PROGRESS when discharge test is occurring. Press **X** to return to the BMM Settings screen.

← Press Enter to set to STOP DISCHARGE TEST screen.



Use the Up/Down buttons to select setting, press Enter ← to set selected setting and return to previous screen. Press Back **X** to return to previous screen without saving changes.



Status will show FAIL when discharge test is not completed. Press Back **X** to return to the BMM Settings screen. Press Enter ← to set status to READY.

NOTE: A discharge test can only be initiated when the battery is fully charged (a fully charged battery will have charge current close to zero amps).

BMS RS-485 Setup (only available on 48-volt system using a BMS-supported battery): Configure the RS-485 BMS Communication to monitor battery parameters and alarms directly from external battery BMS.



← Press Enter to select.




Scroll to highlight parameter in selected sub-menu.

- BMS Comms
- Manage Batteries

← Press Enter to select.



Use the Up/Down buttons to select setting, press Enter  to set selected setting and return to previous screen. Press Back **X** to return to previous screen without saving changes.

After BMS COMMS is enabled, add the bus address either through the autodetection method or the manual selection method.

Bus Address Autodetection

NOTE: The bus address is set on the battery. Refer to the battery's documentation and specifications to determine the bus address, as each battery manufacturer and model has a different implementation of how the DIP switch programs the bus address.



Press Enter to select.



Press Enter to set to SET BUS ADDRESS screen. Press Back **X** to return to previous screen without saving changes.




Press Enter to auto-detect a connected battery.



The screen will show AUTODETECT IN PROGRESS when autodetect sweeps from address 001 to 247 until a battery is detected.



The screen will show NO BATTERY FOUND if autodetect routine fails to identify a connected battery. Press Enter  or Back **X** to return to the Manage Batteries screen.




The screen will display a bus address when the connected battery is detected. Scroll to the ADD BATTERY and press Enter button to auto-detect another bus address.



The system will accept up to four bus addresses. To remove a bus address, press Enter button to go to the REMOVE BATTERY screen.



Use the Up/Down buttons to select setting, press Enter  to set selected setting and return to previous screen. Press Back **X** to return to previous screen without saving changes.

Bus Address Manual Selection

NOTE: The bus address is set on the battery. Refer to the battery's documentation and specifications to determine the bus address, as each battery manufacturer and model has a different implementation of how the DIP switch programs the bus address.



Press Enter to select.



Press Enter button to move to the SET BUS ADDRESS screen. Press Back **X** to return to previous screen without saving changes.



Scroll up to manually select a bus address.



Use the Up/Down buttons to select the bus address (from 001 to 247) set on the connected battery. Press Enter button to set the selected bus address and return to Manage Batteries screen.



A notification will automatically appear indicating a battery communication error if the selected bus address is incorrect.



The screen will display the selected bus address of the connected battery. Scroll to the ADD BATTERY and press Enter to manually select another bus address.



The system will accept up to four bus addresses. To remove a bus address, press Enter button to go to the REMOVE BATTERY screen.



Use the Up/Down buttons to select setting, press Enter to set selected setting and return to previous screen. Press Back X to return to previous screen without saving changes.


View Battery Status (only available on 48-volt system using a BMS-supported battery, if BMS COMMS is enabled): This will show up to four separate Battery Status screens, one for each battery added.



Press Enter to select.




Scroll to view the 2-page Battery Status screen before proceeding to the next screen.



- Voltage
- Current
- Temperature
- SOC


- Capacity
- SOH
- Bus Address



The Battery Status screen will show "Status Unavailable" when there is no battery bus address added, or BMS COMMS is not enabled.



The Battery Status screen will show a 2-page screen with blank parameter values when there is no battery, or no RS-485 cable connected.



VOLTAGE: Shows voltage of battery #x. This number does not specify polarity.

CURRENT: Shows the current that is passing from, or to the battery. This number is negative if the battery is discharging; positive if the battery is being charged; and shows 0A if the battery is fully charged.

TEMPERATURE: Shows the reported temperature of the battery.

SOC: (State of Charge) Shows the reported current charge level of the battery as a percentage of its total capacity. This reflects how much charge is remaining in the battery, expressed as a value from 0% (completely discharged) to 100% (fully charged).

CAPACITY: Shows the reported maximum battery capacity in Ah.

SOH: (State of Health) This will only show if the battery supports SOH reporting. This shows a percentage value that indicates how much capacity the battery has lost compared to its initial capacity. This represents how much of the battery's original capacity is still available after usage and aging.


BUS ADDRESS: Shows the bus address of the connected battery.

3.2.3 Load Distribution Module (if installed)

The LDM Status screen shows the output current for each of the four outputs. Use the Up/Down buttons to scroll through multiple LDM screens (if installed).

Other information will be shown depending on the operating state of the unit:


- QUEUED will be displayed if the output is in the power cycling state
- OFF will be displayed if the output has been disabled
- OPEN will be displayed if the circuit breaker is open or not installed



← Press Enter to move to the LDM Settings.

LDM Settings


The load current level alarm can be set by adjusting the Output Overcurrent, or Output Undercurrent threshold.



Scroll to highlight the sub-menu to change.

- Output Control
- Output Overcurrent
- Output Undercurrent

← Press Enter to select.




Scroll to choose Output to be changed (On/Off control shown).

← Press Enter to select.




Use the Up/Down buttons to adjust setting, press Enter ← to set value and return to previous screen. Press Back **X** to return to previous screen without saving changes.

X Press Back **X** to return to LDM Settings screen.



▲▼ Scroll to highlight the sub-menu to change (Output Undercurrent).

Press Enter to select.



▲▼ Scroll to highlight Output to be adjusted.

⬅ Press Enter to select.



▲▼ Use the Up/Down buttons to adjust setting, press Enter ⬅ to set value and return to previous screen. Press Back X to return to previous screen without saving changes.

3.2.4 Alarm Inputs

The Alarm Inputs Status screen displays the status of the four alarm inputs provided on a unit equipped with the ICM. Use these inputs to monitor voltage free external contact closures such as door sensors, smoke alarm outputs or a water sensor.

Other information will be shown depending on the operating state of the unit:

- Alarm Inputs screen will not be displayed with disabled alarms
- OK will be displayed when there is no change on the state of the contacts
- ALARM will be displayed when a contact activates

Configure the logic of the external contact type selecting Normally Open (NO) or Normally Closed (NC) to activate the alarm inputs using the GUI Alarms Settings & Control tab (see Section 4.6.2). The factory default setting has the alarm inputs disabled.



⬅ Press Enter to see the Alarm History log (see below section for the Alarm History log).

3.2.5 Alarm History

The Alarm History screen displays a log of the 32 most recent alarm events. These alarms may have been raised by any module experiencing an alarm, or by one of the four external Alarm Inputs being triggered.

Other information will be shown depending on the operating state of the unit:

- If there is no alarm history, the screen will display No Alarms in History and the Alarm History log screen will not be displayed.

```

┆ ALARM HISTORY
No Alarms in History
    
```

Alarm History screen if no alarms in history

```

┆ ALARM HISTORY
MODULE #3 ALARM
Breaker 2 Open
Set: 01/01/20 00:00
Alarm is ACTIVE
    
```

Alarm History screen with alarms in history

← Press Enter to see Alarm History log.

```

ALARM HISTORY 1/6
┆
MODULE #3 ALARM
Breaker 2 Open
Set: 01/01/20 00:00
Alarm is ACTIVE
┆
    
```



Scroll through the history screens to see the 32 most recent Alarm events. Shows the module that raised the alarm, date, and time when set, and cleared.

NOTE: The system date and time are normally set by the network. These may be manually set, see GUI, Communications Basic Setup tab (see Section 4.7.1).

3.2.6 Network Status and Advanced Options

The Network Status screen displays the network connectivity, IP address of the system, assigned VID # (if unit has VLAN enabled), and the assigned MAC address.

```

┆ NETWORK STATUS
Modular Power System
100 Base-Tx VID:3
192.168.0.79
9C:95:6E:57:8A:4E
    
```

← Press Enter to move to the Advanced Options screen.

Advanced Options

Use the Advanced Options screen to view the IPv6 addresses, set or clear the LCD Password, Comm Control Restart, Reset Comm Settings, enable or disable VLAN tagging, configure the Ethernet port setup, and view the Device Information.





Scroll to choose parameter or sub-menu.

- IPv6 Addresses
- LCD Password Setup
- Comm Control Restart
- Reset Comm Settings
- VLAN Setup
- Ethernet Port Setup
- Device Information



Press Enter button to select the sub-menu.



Press Back **X** button or Enter  to return to the previous screen.

IPv6 ADDRESSES: Displays the IPv6 addresses assigned to the system. If multiple IPv6 addresses are assigned, use the Up/Down buttons to scroll through the addresses.

LCD PASSWORD SETUP: Set or clear a 4-digit LCD password to lock out the ICM Display adjustments after the LOCKOUT TIMER has expired. Set the display Lockout Timer duration from 0 to 60 minutes. Once the password has been set, it will be required to access all front display settings screens.

NOTE: To reset forgotten passwords, refer to Section 3.3.1.



Press Enter button.



Scroll to choose.

← Press Enter button to select the sub-menu.



▲▼ Use the Up/Down buttons to adjust setting, press Enter ← to set value and return to previous screen. Press Back X to return to previous screen without saving changes.

COMM CONTROL RESTART: Press "Comm Control Restart" to immediately restart the onboard computer and Ethernet port without affecting any of the unit settings and without interrupting DC power to the output terminals.



← Press Enter button to restart.



RESET COMM SETTINGS: Reset the admin password, port settings, and IP address to the factory defaults by pressing the "YES" button in the Reset Comm Settings. This does not affect the LCD password nor user accounts in the GUI (see Section 3.3).



← Press Enter button.



▲▼ Scroll to choose. Press Enter ← or Back X to exit with no change.



▲▼ Scroll to choose. Press Enter ← to reset.



VLAN SETUP: Enable or disable VLAN tagging. Enter the VLAN ID number. After making any changes to the VLAN configuration, restart the controller to have the changes take effect. The controller can be restarted by selecting the "Comm Control Restart" option on the menu.



← Press Enter button.



▲▼ Scroll to choose (default: DISABLED).

← Press Enter button to select the sub-menu.



▲▼ Use the Up/Down buttons to adjust setting, press Enter ← to set value and return to previous screen. Press Back **X** to return to previous screen without saving changes.

NOTE: VLAN should only be enabled if the unit is connected to a network that is configured to support VLAN tagging. If VLAN is enabled, ensure the network is configured to accept the VLAN ID assigned to the unit.



← Press Enter button to choose (default: 1).



▲▼ Use the Up/Down buttons to adjust setting, press Enter ← to set value and return to previous screen. Press Back **X** to return to previous screen without saving changes.

ETHERNET PORT SETUP: Configure the Ethernet port link speed by selecting 1000M (AUTO) for auto-negotiation up to 1000 Mbps, or 100M (AUTO) for auto-negotiation up to 100 Mbps.



← Press Enter button.



▲▼ Use the Up/Down buttons to adjust setting, press Enter ← to set value and return to previous screen. Press Back X to return to previous screen without saving changes.

DEVICE INFORMATION: The Device Information screen displays the part family, installed firmware version, hardware version, and the serial number of the unit.



← Press Enter button.



Press Back X button or Enter ← to return to the previous screen.

3.2.7 Notification Screens

Alarm Notification

When the unit triggers an alarm, the front display panel will be over-written by the Alarms Active screen. Press Back X to return to the previous screen, press Enter ← to jump to the Alarm History screen.



Alarms will be shown as they occur, press Back X button to return to the previous screen, press Enter ← for Alarm History info.

Equalization Charge Notification

When an Equalization Charge is completed, the front display panel will be overwritten with the Equalization Charge results screen.



Press Enter **↵** or Back **X** buttons to jump to the System Status screen.

Discharge Test Notification

When a Discharge Test is completed, the front display panel will be overwritten with the Discharge Test results screen.



A notification will automatically appear indicating the results of a Discharge Test at the completion of the test. Press Enter **↵** or Back **X** buttons to jump to the System Status screen.



A notification will automatically appear indicating a test failure. Press Enter **↵** or Back **X** buttons to jump to the System Status screen.

3.3 Password Reset

3.3.1 LCD Password Reset

NOTE: Always record the LCD password when set, as it must be entered to change any supply settings using the front display panel.

Do the following to clear the LCD password in cases where it is lost:

1. Switch off the AC power to the unit.
2. Simultaneously press the ENTER **↵** and BACK **X** buttons for more than 15 seconds while restoring the AC power.
3. Enter a new password (see Section 3.2.6) if password protection is required.

3.3.2 GUI Password Reset

Reset the GUI password back to the factory default (user: admin, no password) by selecting "RESET COMM SETTINGS" in the Network Status front display panel menu shown above (see Section 3.2.6).

NOTE: The browser cache may need to be cleared for the password reset to be recognized.

3.3.3 User Password Reset

Reset user passwords by following Section 4.7.4.

3.4 Status Indicators and Alarms

The status of the Modular Power Series 2 is indicated on the front display panel module on units equipped with an ICM, or via the network GUI (see Section 4) on remotely monitored units. It is also available through SNMP (see Section 4.7.2). Green "POWER" and red "FAULT" LEDs on the Power Modules, along with the form-C alarm contacts on the rear panel indicate the core status of the unit.

On ICM-equipped systems there is an option on the Settings & Control tab in the GUI for most alarms to send an e-mail to designated addresses for remote notification (see Section 4.7.3). No email will be sent if power is disconnected from the unit, due to loss of network control.

All alarms and warnings will be displayed on the front display screen on Modular Power Series 2 systems and entered in the Alarm History log (most recent 32 alarms listed) (see Section 3.2.5).

Most alarms reset automatically when the trigger condition is removed. Major alarms such as a Module DC Output Failure or Module Configuration Error require that the module be temporarily removed to cycle input power and clear the fault.

Table 20. Power Module Alarms

Alarm Condition	Trigger Condition	Module Output ¹	Red LED	Green LED	Alarm Relay	Send E-mail
Module Operating	Normal operation	Enabled	Off	On	No	No
Power Failure	Loss of AC power to module	Disabled	Off	Off	Active	Yes ²
Configuration Error	Different voltage modules installed	Enabled	Off	On	No	Yes ²
Current Limit (Warning only, display will flash)	Output current approaches within 1 A of the max current limit setting	Enabled	Off	On	No	No
Fan Failure (700 W)	Fan is not operating to spec	Enabled	Off	On	No	Yes ²
Fan Failure (1,000 W)	Fan is not operating to spec or stops spinning	Enabled	Off	On	No	Yes ²
Low Fan RPM (1,500 W)	Fan is not operating to spec	Enabled	Off	On	No	Yes ²
Fan Failure (1,500 W)	Fan stops spinning	Disabled	On	Off	Yes	Yes ²
Manual Disable	Output switched off by ICM or GUI	Disabled	Blink	Off	No	No
Module Removal	Module shelf connections open	Disabled	On	Off	No	No
Power Factor Shutdown	Internal bus voltage out of range	Disabled	On	Off	No	No
Module Fault	Internal aux voltages out of range	Disabled	On	Off	Active	Yes ²
Over Temp Shutdown	Internal temp too high	Disabled	On	Off	Active	Yes ²
DC Output Failure	Output above set point (Manually re-enable DC output to reset)	Disabled	On	Off	Active	Yes ²

¹ Other Power Modules are not affected when one module has its output disabled.

² E-mail notifications only sent if enabled in the unit's web-GUI E-mail Setup page, and either AC or DC power is available for the system to be operational.

Table 21. Battery Management Module (BMM) Alarms

Alarm Condition	Trigger Condition	LVD Contactor	ICM Required	Alarm Relay	Send E-mail
No Alarms	Normal Operation	Closed	No	No	No
Module Power Failure	Loss of AC, and battery disconnected	Open	No	No	Yes ²
Battery Low SOC	SOC drops below Low SOC setting	Closed	Yes	Active ¹	Yes ³
Battery Overcurrent	Battery current rises above overcurrent setting for 10 seconds	Closed	Yes	Active ¹	Yes ³
Circuit Breaker Open	Circuit breaker trips or manually opened	Open	Yes	Active ¹	Yes ³
Battery Over Temperature	Optional TMP probe temp >50°C for 5 s (Lead-acid battery only)	Open	Yes	Active ¹	Yes ³
LVD	Battery V at LVD or Overvoltage setting	Open	No	Active	Yes ³
Configuration Error	BMM in wrong slot or mixed polarity with LDM	Open	No	Active	Yes ³

¹ Contact active only if alarm enabled in the web-GUI BMM Setup page.

² E-mail notifications only sent if enabled in the unit's web-GUI E-mail Setup page, and either AC or DC power is available for the system to be operational.

³ E-mail notifications only sent if enabled in the unit's web-GUI BMM Setup page, and either AC or DC power is available for the system to be operational.

Table 22. Load Distribution Module (LDM) Alarms

Alarm Condition	Trigger Condition	Output Relays	ICM Required	Alarm Relay	Send E-mail
No Alarms	Normal Operation, outputs enabled	Closed	No	No	No
Module Power Failure	Loss of AC and DC bus connection	Open	No	No	Yes ²
Circuit Breaker Open	Circuit breaker opened or tripped	Closed	Yes	Active ¹	Yes ³
Output Undercurrent	Output current drops below setting for 5 s	Closed	Yes	Active ¹	Yes ³
Output Overcurrent	Output current rises above setting for 5 s	Closed	Yes	Active ¹	Yes ³
Configuration Error	LDM in wrong slot or mixed polarity with BMM	No change	Yes	Active ¹	Yes ³
Load Shedding	V drops below Load Shed setting for 30 s	Open	Yes	Active ¹	Yes ³
Output Manually Disabled	Output manually disabled via ICM or GUI page	Open	Yes	No	No

¹ Contact active only if alarm enabled in the web-GUI LDM Setup page.

² E-mail notifications only sent if enabled in the unit's web-GUI E-mail Setup page, and either AC or DC power is available for the system to be operational.

³ E-mail notifications only sent if enabled in the unit's web-GUI LDM Setup page, and either AC or DC power is available for the system to be operational.

Table 23. Intelligent Control Module (ICM) Alarms

Alarm Condition	Trigger Condition	Alarm Relay	Send E-mail
Alarm Input	Contact open or close on any Alarm input 1 to 4	Active (if set up on Alarm Input page)	Yes ²
AC Input Failure	AC input falls below 90 VAC	Active	Yes ³
Shelf Overcurrent	Total output current on shelf is >172 A for 20 s	Active	Yes ³
System Current Limit	ALL Power Modules in system at their current or power limit for 15 s	Active	Yes ³
Communication Bus Error	Internal communication bus error condition	Active	No
Battery Communication Error	No response received from battery after 10 RS-485 transmission attempts	Active ¹	Yes ⁴
Power Save Error	Power Save operation cycles five times in 60 minutes	No	No

¹ Contact active only if alarm enabled in the web-GUI BMM Setup page.

² E-mail notifications only sent if enabled in the unit's web-GUI Alarms Setup page, and either AC or DC power is available for the system to be operational.

³ E-mail notifications only sent if enabled in the unit's web-GUI E-mail Setup page, and either AC or DC power is available for the system to be operational.


⁴ E-mail notifications only sent if enabled in the unit's web-GUI BMM Setup page, and either AC or DC power is available for the system to be operational.

4.0 OPERATION: GRAPHICAL USER INTERFACE

Connect to the Intelligent Modular Power Series 2 via Ethernet for full, secure access to all system settings, status, and alarm conditions. Units with the Intelligent Control Module (ICM) installed are equipped with a built-in web server that can be accessed via any standard web browser on a network connected computer or phone. No additional software is required on the unit.

4.1 Log In/Log Out

1. Connect to the Modular Power Series 2 by entering the IP address of the unit in the location/address field of the browser as shown:



The default IP address of the unit is "192.168.0.180", but any unit connected to a network with a DHCP server will be assigned a different IP address automatically. To find the assigned address use


the front display screen on the unit and navigate to the Network Status screen (see Section 3.2.6).

NOTE: Take note of the assigned IP address displayed and use this in the browser address field to access the unit remotely.

NOTE: If connecting directly from a computer to the Modular Power Series 2 the computer must be configured with an IP address on the same network subnet as the unit. This is not required for a network connection (See Section 4.7.2).

The IP address of any ICT unit on a local network can be found by running the ICT "IP Address Discovery tool", after installing it on a Windows computer connected to the same network (tool available for download from ICT <http://www.ict-power.com/resources/tools-utilities/>). This tool does not support macOS.

2. Log into the unit's built-in server when prompted with the username and password. The default username is "admin", and no password is required as the factory default.



The image shows a screenshot of the 'User Authentication' screen. At the top left is the ICT logo with the tagline 'The Power of Reliability'. Below the logo is a header bar with the text 'User Authentication'. Underneath the header bar are two input fields: 'User Name:' with the text 'admin' entered, and 'Password:' with an empty field. At the bottom center is a 'Log In' button.

To log out of the ICT Modular Power Series 2 Graphical User Interface (GUI), click the Logout link on the header. The system will also automatically log off the user after 20 minutes of inactivity.


4.2 System

Once successfully logged in, the Status page of the System tab will be shown in the browser. All tabs have the same header that displays the

name, model number, IP address, and firmware version number of the unit. Click the ICT logo to visit the ICT website.

4.2.1 STATUS

This tab provides the operating status of the unit.



Modular Power System
Modular Power Series 2 (48V)
IP Address: 192.168.0.147
Firmware: v0.36
[Logout]

STATUS | SETTINGS & CONTROL

System Status

Important: Set the Administrator password for this device.

DC Output	
Output Status:	Enabled
Output Voltage:	53.9 VDC
Total System Current:	2.1 A

AC Mains	
Input Voltage:	120 VAC

Environmental	
Probe Temperature:	25 °C

System Alarms	
Form C Alarm:	Alarm
Power Module #1:	OK
Power Module #2:	OK

Module #3 : Battery Management	
Battery Voltage:	53.9 VDC
Battery Current:	0.0 A
Total Capacity:	416 Ah
Remaining Capacity:	407 Ah
Run-Time Remaining:	-
Battery State of Charge:	97 %
Battery 2 Voltage:	53.9 VDC
Alarm Status:	OK

Module #4 : Load Distribution	
Output #1: Radio 1	QUEUED
Output #2: Radio 2	OFF
Output #3:	OPEN
Output #4: RF Amplifier	2.0 A
Alarm Status:	Alarm

Copyright © 2025 Innovative Circuit Technology Ltd.

DC Output

Output Status: Shows status of the DC output. Will show Enabled if providing DC output or Disabled if not.

Output Voltage: Shows output DC voltage. This is an absolute value and does not specify polarity.

Total System Current: Shows total amps being supplied by the unit. This includes loads and battery charging.

AC Mains

Input Voltage: Shows the input AC voltage.

Environmental

Probe Temperature: Shows the temperature measured on the optional ICT Battery Temperature Probe (ICT-TMP), if installed. The temperature shows blank if there is no probe installed.

System Alarms

Form C Alarm: Shows whether the unit is broadcasting a form-C alarm. (Alarm or OK).

Power Module #x: Shows status of the installed Power Modules (Alarm or OK).

Module #x: Battery Management

If the optional Battery Management Module (BMM) is installed, this section will show the status of the connected batteries. The section will be labelled with the module number.

Battery Voltage: Shows voltage of battery #1 measured on the BMM terminals. This number does not specify polarity.

Battery Current: Shows the current that is passing from, or to the batteries. This number is negative if the battery is discharging; positive if the battery is being charged; and shows 0A if the battery is fully charged. This number represents both batteries if this is a dual BMM (BMMD).

Total Capacity: Shows the total maximum capacity in Ah as reported by the battery BMS. This field only displays if BMS Communication is enabled.

Remaining Capacity: Shows the current total capacity in Ah as reported by the battery BMS. This field only displays if BMS Communication is enabled.

Net Ah Count: Shows the Ah that have been consumed from the battery. Will display 0 Ah if the batteries are fully charged. This field will not be displayed if BMS Communication is enabled.

Run-time Remaining: Shows the estimated time in hours and minutes before the battery is discharged. This is blank if the batteries are charging.

NOTE: The Run-time Remaining and Battery State of Charge values shown are estimated.

Battery State of Charge: Shows the estimated state of charge in %.

The system resets the SOC to 100% whenever it detects that the battery is at the rated Float Voltage with minimal charge current for at least 8 hours with lead-acid, or 1 hour with lithium batteries. The system compares the user-entered Battery Capacity to the Net Ah Count to determine the remaining charge.

If BMS Communication is enabled, this field displays information from the battery on-board BMS. This information is updated every 5 seconds for each battery added to the system.

Battery 2 Voltage: Shows the voltage of battery #2 measured on the BMM terminals. This field only displays when a BMMD is installed.

Alarm Status: Shows status of the batteries (Alarm or OK).

Module #x: Load Distribution

If the optional Load Distribution Module (LDM) is installed, this section will show the status of the four LDM outputs; the section will be labelled with the module number.

Output #x: Shows name and status of the output. Will show amps of current being drawn. Will show OFF if the output is disabled. Will show OPEN if the breaker is turned off or has tripped due to an overcurrent event, or not installed. Will show QUEUED if the output is in the power cycling state.

Alarm Status: Shows status of the LDM. (Alarm or OK).


4.2.2 SETTINGS & CONTROL

This tab is used to adjust the System Output Settings.

DC Output Status

On/Off Buttons: Use these to remotely disable the system output by shutting off all Power Modules. The default setting is Enabled.

Auto-Restart Button: Use this button to momentarily shut off the main output and then restart automatically after a time delay (set in the "Auto-Restart Delay" field). This feature can be used to remotely force connected equipment to re-boot.



The screenshot shows the web interface for the Modular Power System. The top right corner displays the system name "Modular Power System" and details: "Modular Power Series 2 (48V)", "IP Address: 192.168.0.75", "Firmware: v0.52", and a "[Logout]" link. The main navigation menu on the left includes "System", "Power Modules", "Battery Backup", "Load Distribution", "Alarms", "Communications", and "Help". The "SETTINGS & CONTROL" tab is active, showing the "System Control" section with a "DC Output Status" area. A green "Enabled" indicator is present, along with "On", "Off", and "Auto-Restart" buttons. Below this, explanatory text states: "The 'Auto-Restart' button will disable the DC Output for the time set in the 'Auto-Restart Delay' field. The DC Output will be automatically re-enabled after this time delay. The DC Output cannot be disabled during an AC Failure." The "System Output Settings" section contains "Output Settings" with "Output Voltage" set to 54.0 VDC (range 46.0 - 62.0) and "Current Limit" set to 232.0 A (range 3.0 - 232.0). A note specifies: "Actual System Current Limit will be the lesser of the Current Limit setting and the Maximum Output Capacity of the installed Power Modules." The "Auto-Restart Delay" section has "Auto-Restart Delay" set to 15 seconds (range 5 - 240). A "Save Settings" button is at the bottom. The footer reads "Copyright © 2025 Innovative Circuit Technology Ltd."

Output Settings

Output Voltage: Set the system "Output Voltage" to match the float voltage requirement for the external battery. The default setting varies based on the Power Modules installed (see Table 8).

Current Limit: Set the system output "Current Limit", to limit the total current that can be drawn by all the external loads and charging the battery. The default setting varies based on the Power Modules installed (see Table 8).

Auto-Restart Delay

Auto-Restart Delay: Set the delay time (5 to 240 seconds) that the output will remain off when output is remotely disabled using the "Auto-Restart" button. The unit will automatically restart after the Auto-Restart Delay period. The default setting is 15 seconds.

NOTE: The output voltage and current limit settings apply to the combined output of all installed Power Modules. The ICM treats the combined modules as a single high-power supply. Adjust the system Output Voltage and Current Limit (see Section 4.2.2) to match the battery type and system load requirements if required.


4.3 Power Modules

Use this tab to see the status of all installed Power Modules in the unit and to control their settings.

4.3.1 STATUS

This tab shows the operating status of the installed Power Modules.

The graphic will display green for an installed Power Module that is working as expected; a red display for an installed Power Module that has an active alarm; and will be grey when a Power Module is not installed in that slot.



Modular Power System
Modular Power Series 2 (48V)
IP Address: 192.168.0.167
Firmware: v0.56
[Logout]

System | **Power Modules** | Battery Backup | Load Distribution | Alarms | Communications | Help

STATUS | **SETTINGS & CONTROL**

Power Modules - Status

Module Status

Module:	Type:	Status:	Serial Number:
#1:	Power Module (1000W)	OK (Power Save)	347000072
#2:	Power Module (1000W)	OK	347000075
#3:	Power Module (1000W)	OK	348820028

Module Status

Shows the slot that the Power Module is installed in; the rating of the Power Module; the status (Alarm, OK, or OK (Power Save)); and the Serial Number of the Power Module (only available for ICT1000-48PM).

Power Module Capacity

Power Module Capacity	
Online Power Modules:	2
Online Power Module Capacity:	54.0 A
Total System Power Capacity:	3000 W
System Output Power:	3 W
Load Rate:	0 %

Online Power Modules: Shows the number of active Power Modules installed in the system.

Online Power Module Capacity: Shows the combined maximum output capacity (in amps) for all installed Power Modules.

Total System Power Capacity: Shows the combined maximum output power capacity (in watts) for all installed Power Modules.


System Output Power: Shows the total power (in watts) being supplied by the system. This includes all loads and battery charging.

Load Rate: Shows the load utilization rate of the system.

4.3.2 SETTINGS & CONTROL

(only available when there are at least three ICT1000-48PM installed)

This tab is used to adjust the power save settings.



Power Save Settings (ICT1000-48PM only)

The Power Save function is designed to reduce energy consumption under light system loads by reducing the number of active power modules. Operating with fewer active modules at low loads improves energy efficiency compared to having multiple modules running simultaneously. To ensure reliability and N+1 redundancy, at least two power modules remain active at all times.

Power Save mode will activate when:

- Total System Current is less than the Enter Power Save threshold, and
- There are at least three ICT1000-48PM installed, and
- A battery is connected with a closed LVD

The system will enter power save mode and start putting one Power Module at a time into standby after 60 seconds.

The system will exit power save mode and begin activating one Power Module at a time, 60 seconds after the Exit Power Save threshold is exceeded, or if there are less than three 1,000-watt Power Modules installed, or if the battery LVD opens.

To ensure even usage on the Power Modules, the active modules will be cycled every 7 days of continued power save operation. It takes 120 seconds for the whole cycle time; this includes enabling one of the modules in standby and putting into standby one of the previously enabled Power Modules, in sequential order.

In the event of frequent transient loads, the user will be prompted with a Power Save Error alarm. This alarm is triggered if power save operation cycles (exits and enters) five times in 60 minutes. This alarm will not be cleared up until 1 day after the alarm is triggered.

Enable Power Save: Select the check box to activate Power Save feature.

Enter Power Save below: Set the Total System Current threshold (%) that will activate Power Save mode. When Total System Current is below the set percentage of Power Module Capacity, the system will progressively place unneeded Power Modules into standby mode. Power Modules in standby mode will have blinking green LEDs and fans turned off. The default is 40%.

Exit Power Save above: Set the Total System Current threshold (%) that will trigger the end of Power Save mode. When Total System Current exceeds the set percentage of Power Module Capacity, the system will gradually power up the standby Power Modules, one at a time, until the Total System Current is below this threshold. The default is 80%.

4.4 Battery Backup (if installed)

Use this tab to see the status of the connected batteries and to control their settings.

The graphic will display green for an installed BMM that is working as expected; a red display for an installed module that has an active alarm; and will be grey when a module is not installed in that slot.

4.4.1 STATUS

This tab shows the operating status of the connected batteries. If BMS is enabled, there will be separate battery status for each battery.


Module Status

Shows the slot that the BMM is installed in and the status (Alarm or OK)

Module #x: Battery Management

Battery Voltage: Shows voltage of battery #1 measured on the BMM terminals. This number does not specify polarity.

Battery Current: Shows the current that is passing from, or to the battery. This number is negative if the battery is discharging; positive if the battery is being charged; and shows 0A if the battery is fully charged. This number represents both batteries if this is a dual BMM (BMMD).



Modular Power System
 Modular Power Series 2 (48V)
 IP Address: 192.168.0.187
 Firmware: v0.56
 [Logout]

STATUS **SETTINGS & CONTROL**

Battery Backup - Status

Module Status

Module:	Type:	Status:
#3:	Battery Management	OK

Module #3 : Battery Management

Battery Voltage:	53.9 VDC
Battery Current:	0.0 A
Total Capacity:	416 Ah
Remaining Capacity:	407 Ah
Run-time Remaining:	-
Battery State of Charge:	97 %
Battery 2 Voltage:	53.9 VDC
LVD Disconnect Voltage:	42.0 VDC
LVD Reconnect Voltage:	50.0 VDC
LVD Status:	Closed
Alarm Status:	OK

Battery #1 : Narada	
Voltage:	49.9 VDC
Current:	0.0 A
Temperature:	22 °C
Battery Capacity:	102 Ah
State of Charge:	98 %
State of Health:	-
Bus Address:	38

Battery #2 : Narada	
Voltage:	49.9 VDC
Current:	0.0 A
Temperature:	22 °C
Battery Capacity:	104 Ah
State of Charge:	98 %
State of Health:	-
Bus Address:	40

Battery #3 : Narada	
Voltage:	49.9 VDC
Current:	0.0 A
Temperature:	22 °C
Battery Capacity:	104 Ah
State of Charge:	98 %
State of Health:	-
Bus Address:	41

Battery #4 : Narada	
Voltage:	50.0 VDC
Current:	0.0 A
Temperature:	22 °C
Battery Capacity:	106 Ah
State of Charge:	97 %
State of Health:	-
Bus Address:	42

Copyright © 2025 Innovative Circuit Technology Ltd.



Leave BMM or BMMD breaker(s) turned off until the software has been configured (see Section 3.2.2 or Section 4.4.2).

Total Capacity: Shows the total maximum capacity in Ah as reported by the battery BMS. This field only displays if BMS Communication is enabled.



Remaining Capacity: Shows the current total capacity in Ah as reported by the battery BMS. This field only displays if BMS Communication is enabled.

Net Ah Count: Shows the Ah that have been consumed from the battery. Will display 0 Ah if the batteries are fully charged. This field will not be displayed if BMS Communication is enabled.

Run-time Remaining: Shows the estimated time in hours and minutes before the battery is discharged. This is blank if the batteries are charging.

NOTE: The Run-time Remaining and Battery State of Charge values shown are estimated.

Battery State of Charge: Shows the estimated state of charge in %. The system resets the SOC to 100% whenever it detects that the battery is at the rated Float Voltage with minimal charge current for at least 8 hours with lead-acid, or 1 hour with lithium batteries. The system compares the user-entered Battery Capacity to the Net Ah Count to determine the remaining charge.

If BMS Communication is enabled, this field displays information from the battery on-board BMS. This information is updated every 5 seconds for each battery added to the system.

Battery 2 Voltage: Shows the voltage of battery #2 measured on the BMM terminals. This field only displays when a BMMD is installed.

LVD Disconnect Voltage: Shows the battery voltage when the LVD will disconnect the battery.

LVD Reconnect Voltage: Shows the battery voltage when the LVD will reconnect the battery.

LVD Status: Shows the status of the LVD (Open or Closed).

Alarm Status: Shows status of the batteries (Alarm or OK).

Battery #x: Battery Model (BMS-Supported)

This section is only available if BMS Communication field is configured in Section 4.4.2. This information is provided by the battery's BMS.

Voltage: Shows voltage of battery #x. This number does not specify polarity.

Current: Shows the current that is passing from, or to the batteries. This number is negative if the battery is discharging; positive if the battery is being charged; and shows 0A if the battery is fully charged.

Temperature: Shows the reported temperature of the battery.

Battery Capacity: Shows the reported maximum battery capacity in Ah.

State of Charge: Shows the reported current charge level of the battery as a percentage of its total capacity. This reflects how much charge is remaining in the battery, expressed as a value from 0% (completely discharged) to 100% (fully charged).

State of Health: This will show blank if the battery does not support State of Health reporting. This shows a percentage value that indicates how much capacity the battery has lost compared to its initial capacity. This represents how much of the battery's original capacity is still available after usage and aging.


Bus Address: Shows the bus address of the connected battery.

4.4.2 SETTINGS & CONTROL

This tab is used to adjust the settings of the BMM.



Always consult battery manufacturer's specifications when selecting battery type. Incorrect battery type setting may damage the battery. If Lithium-Ion type battery is selected, an integrated battery management system (BMS) must be used to protect the battery cells from inappropriate voltage or current levels.



Configure Battery

Battery Type: Configure the Battery Type of the battery used in the system (Lead Acid or Lithium Ion).

Table 24. List of Battery Types

Battery Type	Description	BMS-Supported
Lead Acid		no
Lithium (Cyclone)	Cyclone Brand batteries	yes
Lithium (EG4 LL)	EG4 Electronics Brand batteries	yes
Lithium (Narada)	Narada Brand batteries	yes
Lithium (PWRSS)	Power Storage Solutions	yes
Lithium (viaPhoton)	viaPhoton Brand batteries	no
Lithium (Other)		no

Battery Model (only available for Lithium Ion): Configure the Battery Model of the Lithium-Ion battery used in the system.

NOTE: PWRSS is an abbreviation for Power Storage Solutions.

Battery Capacity: Set the "Battery Capacity" in Ah (40 to 2000 Ah) of the total battery pack connected to the unit. This value is used by the unit when estimated Run-time Remaining. The default setting is 100 Ah.

Rate: Set the discharge "RATE" (in hours) as specified by the battery manufacturer to determine the battery capacity. Normally the 10- or 20-hr rate is used. The system will use this information to help estimate the Battery State of Charge, and remaining battery capacity when in use. The default setting is 10 hr.

NOTE: Connecting batteries in parallel will increase the total Ah capacity, while connecting batteries in series will increase the voltage with no change to the Ah capacity.

Output Voltage Control (only available on lead-acid batteries)

Output Voltage Control

Temperature Coefficient / cell: mV/°C

Temperature Coefficients / Cell: Set the battery voltage Temperature Coefficient / Cell to optimize the automatic control of the lead-acid battery charging voltage, to keep the battery in a good state of health. This setting is only available if the system is configured for use with a lead-acid type battery.



Adjust this setting to match the battery manufacturer's recommended compensation value in $-mV/^{\circ}C$ per cell. This value will typically be $-4 mV/^{\circ}C$ for a flooded lead-acid battery (i.e., will compensate output voltage $-24 mV/^{\circ}C$ for a 6-cell 12 V battery) to help ensure the battery is fully charged in cold locations, and is not overcharged when warm. The numbers in the drop-down field are absolute values. The default setting is $0 mV/^{\circ}C$.

NOTE: The system must have the battery temperature sensor (ICT-TMP) installed on the battery for this setting to have an effect (default setting is $0 mV/^{\circ}C$, assumes $25^{\circ}C$ operation).

BMS RS-485 Communication (only available on 48-volt system using a BMS-supported battery)

BMS RS-485 Communication

Enable BMS Communication:

Enable BMS Communication: Select this checkbox to enable communication with the BMS.

Bus Addresses: This field is only available if BMS Communication is enabled.

BMS RS-485 Communication

Enable BMS Communication:

Bus Addresses:

Battery #1:	<input type="text" value="42"/>	<input type="button" value="Remove"/>
Battery #2:	<input type="text" value="41"/>	<input type="button" value="Remove"/>
Battery #3:	<input type="text" value="38"/>	<input type="button" value="Remove"/>

Use the "Add" button to enter up to four bus addresses. Use the "Remove" button to remove previously added addresses.

NOTE: The bus address is set on the battery. Refer to the battery's documentation and specifications to determine the bus address, as each battery manufacturer and model has a different implementation of how the DIP switch programs the bus address.

Once BMS RS-485 Communication is activated and correctly configured, the battery parameters will be displayed on the Battery Backup Status page (see Section 4.4.1).



Battery Charge Current Limit

Battery Charge Current Limit		
Charge Current Limit:	<input type="text" value="150"/>	A (10 - 150)
Consult battery manufacturer's recommendations for appropriate charge current setting.		

Charge Current Limit: Set the maximum current that the unit may provide while still allowing the full rated current to be drawn from the main output. This setting should be set to the value recommended by the battery manufacturer. The default setting is 150 amps.

Equalize Charge (only available on lead-acid batteries)



Risk of serious personal injury or damage to equipment and property! Always observe the following:

- Equalize charging is intended for flooded lead-acid batteries only and may produce higher than normal levels of hydrogen gas.
- Consult with the battery manufacturer when using SLA batteries.
- **Do not use equalization charging with sealed or lithium-ion batteries.**
- Ensure the battery compartment is well ventilated to avoid any risk of explosion.
- Always consult with and observe all battery manufacturer recommendations.

Set up manual or automatic equalize charge cycles for flooded lead-acid batteries. This setting is only available if the system is configured for use with a lead-acid type battery.

The connected load devices should continue to run normally while the equalization charge is running.

The unit's log (see Section 4.7.1) will record the completion of the equalization charge.

Equalize Voltage: Set this to the battery manufacturer's recommended value for an equalize (or boost) charge (for flooded lead-acid batteries only). A regular high-voltage equalization charge will help prevent stratification of the electrolyte in the battery and can help extend its life. The default setting varies based on the Power Modules installed.

Equalize Charge	
Equalize Voltage:	<input type="text" value="60.0"/> VDC (46.0 - 62.0)
Equalize Duration:	<input type="text" value="60"/> minutes (10 - 240)
Equalize Interval:	<input type="text" value="0"/> days (0 - 180)
Day of Week:	<input type="text" value="Any"/>
Start Time:	<input type="text" value="00"/> : <input type="text" value="00"/> (HH : MM)
Caution: For use with flooded batteries only (see Instruction Manual).	
Periodic Equalize Charge will be disabled if the Equalize Interval is set to 0 days or if NTP synchronization is not configured.	
The Battery must be fully charged and the DC Output enabled before a Equalize Charge can be started.	
<div style="border: 1px dashed gray; padding: 5px;"> Start Manual Equalize Charge: <input type="button" value="Start Charge"/> </div>	
Last Equalize Charge:	01/21/25 15:51:34
Charge Time:	0 min
Next Equalize Charge:	Disabled

Table 25. Default Equalize Voltage Settings

Module	ICT700-12PM	ICT700-24PM ICT1500-24PM	ICT1000-48PM ICT1500-48PM
Voltage	15 VDC	30 VDC	60 VDC

Equalize Duration: Set the time in minutes (10–240 minutes) for the equalize charge voltage to be applied (as recommended by the battery manufacturer). The default setting is 60 minutes.

Equalize Interval: Set the time in days (0–180 days) between automatic equalize charges. Set this time to 0 to disable the automatic equalize charge. The default setting is 0 (Disabled).

Day of Week: Set the day of the week that the automatically recurring equalize charge should take place or select "Any" to allow an equalize charge to take place on any day of the week. Day of Week takes precedence over Equalize Interval. The default setting is Any.

Start Time: Set the time of day for automatically recurring equalize charges to start. The time must be entered using 24-hour time format. The default setting is 00:00.

NOTE: NTP Time Synchronization must be enabled on the Communications Basic Setup page to enable automatically recurring equalize charges.

An Equalize Charge can only be initiated when the battery is fully charged (a fully charged battery will have charge current close to zero amps). If the system is unable to start an equalize charge at the selected Start Time, it will attempt again at the

same time next day, or next week if a specific Day of Week is selected.

An Equalization Charge will immediately be terminated if AC power fails.

Manual Equalize Charge: Press this button to manually initiate an equalize charge for the set duration time once the battery is fully charged.

NOTE: System will state that Manual Equalize Charge is Not Ready if battery is not yet fully charged.

Last Equalize Charge: Shows the date and time that the last equalization charge was performed.

Charge Time: Shows the duration of the last equalization charge.

Next Equalize Charge: Shows the scheduled date and time of the next automatic equalize charge, if an Equalize Interval has been set. This information is to help track where the system is within the automatic charge cycle.

LVD Settings

LVD Settings			
Disconnect Voltage:	<input type="text" value="42.0"/>	VDC	(38.0 - 48.0)
Reconnect Voltage:	<input type="text" value="50.0"/>	VDC	(42.0 - 52.0)
<small>Consult battery manufacturer's recommendations for appropriate settings.</small>			

The low voltage disconnect (LVD) protects the battery from excessive discharge by disconnecting the battery when the battery reaches a preset voltage. The battery is reconnected when AC power is restored or after recharging to a preset threshold.

The reconnect voltage setting will be used when charging the battery from an external DC source (such as a solar system), otherwise once AC power returns the LVD contactor will automatically close so that the Power Modules can charge the battery directly.

NOTE: For lead-acid battery, the LVD contactor will not close if the lead-acid battery is less than 40 volts on a 48-volt system (see Table 26). The unit believes the battery is deeply discharged, and possibly damaged. A deeply discharged battery will not be reconnected as a safety measure. The battery will need to be manually checked for

proper function and then manually charged to at least 40 volts (on a 48-volt system) before the LVD will close. Refer to the battery manufacturer's recommendations on how to proceed with a deeply discharged battery. This does not apply to the system when the Lithium setting has been chosen.

Table 26. Deeply Discharged Battery Values (typical)

12 VDC Units	24 VDC Units	48 VDC Units
10 VDC	20 VDC	40 VDC

Disconnect Voltage: Set the threshold to a level that will protect the battery from excessive discharge (as recommended by the battery manufacturer). The LVD contactor will open when the battery discharges to this level for at least 3 seconds. The default setting varies based on the Power Modules installed.

Table 27. Default Disconnect Voltage Settings

Module	ICT700-12PM	ICT700-24PM ICT1500-24PM	ICT1000-48PM ICT1500-48PM
Threshold Voltage	10.5 VDC	21.0 VDC	42.0 VDC

Reconnect Voltage: Set the level where the unit will reconnect to the battery after it has recharged (as recommended by the battery manufacturer). The "Reconnect Voltage" must be higher than the Disconnect Voltage to prevent the LVD contactor repeatedly cycling on and off. The default setting varies based on the Power Modules installed.

Table 28. Default Reconnect Voltage Settings

Module	ICT700-12PM	ICT700-24PM ICT1500-24PM	ICT1000-48PM ICT1500-48PM
Threshold Voltage	12.5 VDC	25.0 VDC	50.0 VDC

Table 29. The Minimum Difference Between Disconnect and Reconnect Voltage

12 VDC Units	24 VDC Units	48 VDC Units
1.5 V	2 V	4 V

Battery Over-Current Alarm

Battery Over-Current Alarm

Over-Current Threshold: > A (0 - 150)

Over-Current Alarm will be disabled if the threshold is set to 0 Amps.



Damage to the unit, load, and/or personal injury may occur if the battery current through the BAT terminal exceeds 150 amps.

Over-Current Threshold: Set the threshold to receive an alarm notification when the battery discharge or charge current exceeds a set overcurrent level. Set the threshold to 0 amps to disable this alarm. The default setting is 0 (Disabled).

Battery Low SOC Alarm

Battery Low SOC Alarm	
SOC Threshold:	< <input type="text" value="0"/> %

SOC Threshold: Set this to receive an alarm notification when the battery state of charge falls below the specified level. Set the threshold to 0 amps to disable this alarm. The default setting is 0 (Disabled).

Alarm Reporting

Ignore Circuit Breaker 2 Status: Select this checkbox to prevent alarm e-mails being sent when a single battery is connected to a BMMD. This setting is only available if a BMMD is installed. The default setting is Disabled.

BMS Protection conditions: Select this checkbox to display alarms for battery protection conditions reported by the external battery BMS. This field is only available if the BMS Communication is enabled. The default settings is enabled.

Alarm Reporting	
Ignore Circuit Breaker 2 Status:	<input type="checkbox"/>
Display alarms for:	
BMS Protection conditions:	<input checked="" type="checkbox"/>
When an alarm is triggered on this module,	
Activate Alarm Form C Contact:	<input checked="" type="checkbox"/>
Send E-mail:	<input type="checkbox"/>

Activate Alarm Form C Contact: Select this checkbox to have the rear panel alarm contacts change state for an alarm condition. The default setting is Enabled.

Send E-mail: Select this checkbox to have an e-mail sent to the e-mail addresses set up on the communications page for an alarm condition (see Section 4.7.3). The default setting is Disabled.

Battery Discharge Test



NOTICE

This test must only be done when AC power is present during the test and for an adequate time after the test to allow for a full recharging of the battery. Otherwise, the battery may not have sufficient remaining capacity to power the load during an AC power outage.

Configure the Battery Discharge Test settings in this section to either manually or automatically perform a partial discharge test to gauge the relative capacity of the external lead-acid battery. Limit the depth of discharge to no more than 50% of the nominal battery capacity to avoid stressing the battery due to a deep discharge.

When the test is run, the output voltage from the Power Modules will be reduced so that the external battery will power the system load until the "Set Discharge Time" limit, the "Set Discharge Voltage Limit" or the "Maximum Discharge Limit" is reached.

A "Discharge Test Complete" notification indicates the battery can power the connected load for the set test duration while maintaining its voltage above the Discharge Voltage Limit. This notification is displayed on the front display panel and is delivered via e-mail if messaging is configured via the GUI (see Section 4.7.3).

The unit's data log (see Section 4.7.1) will record the completion of the discharge test.

A "Discharge Test Failure" notification indicates the battery is unable to power the load for the set duration. This notification is displayed on the front display panel and is delivered via e-mail if messaging is configured via the GUI (see Section 4.7.3).

The connected load devices should continue to run normally while the discharge test is running.

Set Discharge Time: Set the maximum time for the test in minutes (10–240 minutes) that the test will run. The default setting is 60 minutes.

Battery Discharge Test

Set Discharge Time: minutes (10 - 240)

Set Discharge Voltage Limit: VDC (42.5 - 52.0)

Maximum Discharge Limit: Ah (0 - 600)

Discharge Test Interval: days (0 - 180)

Day of Week:

Start Time: : (HH : MM)

Periodic Battery Discharge Tests will be disabled if the Discharge Test Interval is set to 0 days or if NTP synchronization is not configured.

Set Maximum Discharge Limit to 0 Ah for no limit.

Discharge Voltage Limit must be set higher than the LVD Disconnect Voltage.

The Battery must be fully charged and the DC Output enabled before a Battery Discharge Test can be started.

Manual Discharge Test is **Not Ready**.

Last Battery Discharge Test: -

Status: -

Discharge Time: -

End Voltage: -

Amp-Hours Discharged: -

Next Periodic Discharge Test: *Disabled*

Set Discharge Voltage Limit: Set the minimum battery voltage which will terminate the test. The default setting varies based on the Power Modules installed.

Table 30. Default Discharge Voltage Limit Settings

Module	ICT700-12PM	ICT700-24PM ICT1500-24PM	ICT1000-48PM ICT1500-48PM
Threshold Voltage	11 VDC	22 VDC	44 VDC

Maximum Discharge Limit: Set the maximum battery capacity in amp-hours that can be discharged before the test will be terminated. Set this to 0 Ah for no limit. The default setting is 0 (no limit).

Discharge Test Interval: Set the time in days (0–180 days) between automatic discharge tests. Set this time to 0 to disable automatic discharge tests. The default setting is 0 (Disabled).

Day of Week: Set the day of the week that the automatically recurring discharge test should take place or select "Any" to allow a discharge test to take place on any day of the week. Day of Week takes precedence over Discharge Time Interval. The default setting is Any.

Start Time: Set the time of day for an automatically recurring discharge test to start. The time of time must be entered using 24-hour time format. The default setting is 00:00.

NOTE: NTP Time Synchronization must be enabled on the Communications Basic Setup page to enable automatic Discharge Tests.

A discharge test can only be initiated when the battery is fully charged (a fully charged battery will have charge current close to zero amps). If the system is unable to start a Discharge Test at the selected Start Time, it will attempt again at the same time next day, or next week if a specific Day of Week is selected.

A discharge test will immediately fail if the unit loses AC power. The log will show that the test failed.

Manual Discharge Test: Press this button to manually initiate a Battery Discharge Test of a fully charged battery.

NOTE: System will state that the discharge test is Not Ready if the battery is not fully charged (a fully charged battery will have charge current close to zero amps).

Last Battery Discharge Test: Shows the date and time that the last discharge test was performed.

Status: Displays the end status of the last discharge test (Complete or Fail).

Discharge Time: Shows the time in minutes that the test lasted.

End Voltage: Shows the battery voltage when the test ended.

Amp-Hours Discharged: Shows the amp-hours discharged during the test.


Next Periodic Discharge Test: Shows the scheduled date and time of the next automatic discharge test if a Discharge Test Interval has been set. This information is to help track where the system is within the automatic charge cycle.

NOTE: Save Settings before leaving this tab.

4.5 Load Distribution (if installed)

Use this tab to see the status of the installed circuit breakers and to control their settings. This tab is only present if the optional Load Distribution Module (LDM) is installed.

The graphic will display green for an installed LDM that is working as expected; a red display for an installed module that has an active alarm; and will be grey when a module is not installed in that slot.



The screenshot shows the 'Load Distribution - Status' page. At the top, there are tabs for 'STATUS' and 'SETTINGS & CONTROL'. Below the tabs is a row of four status indicators labeled 1, 2, 3, and 4. Indicator 4 is highlighted in green, indicating an installed and working module. Below this is a 'Module Status' table:

Module:	Type:	Status:
#4:	Load Distribution	OK

Below the table is a section titled 'Module #4 : Load Distribution' with the following details:

Output #1:	Radio 1	0.0 A
Output #2:	Radio 2	0.0 A
Output #3:	Repeater	0.0 A
Output #4:	RF Amplifier	2.0 A
Alarm Status:	OK	

At the bottom of the page, it says 'Copyright © 2025 Innovative Circuit Technology Ltd.'

4.5.1 STATUS

This tab shows the operating status and current loads of the circuit-breaker controlled outputs on the LDM module.

If there is more than one LDM installed, they will show individually.

Module Status

Shows the slot that the LDM is installed in and the status (Alarm or OK).


Module #x: Load Distribution

Output #x: Shows name and status of the output. Will show amps of current being drawn. Will show OFF if the output is disabled. Will show OPEN if the breaker is turned off or has tripped due to an overcurrent event, or not installed. Will show QUEUED if the output is in the power-cycling state.

Alarm Status: Shows status of the LDM (Alarm or OK).

4.5.2 SETTINGS & CONTROL

This tab is used to adjust the setting on the LDM. There will be a separate tab for each LDM that is installed in the unit.



Module Output Control

Each output on the LDM will be displayed with name and status (Enabled, Disabled, Queued). A green Enabled indicates the electronic relay is closed or turned on. A red Disabled indicates that the electronic relay is open or turned off. An orange Queued indicates that the output is in the power cycling state.

Select the "On" or "Off" buttons to enable or disable the output. This will not affect the mechanical circuit breaker. The default setting is Enabled.

NOTE: The "Off" button will be replaced with a "Cycle" button if the Power Cycling is enabled in the Module Output Configuration settings.

Master Output Control

Select "All Outputs On" or "All Outputs Off" to enable or disable all four output channels simultaneously.

NOTE: Outputs with Power Cycling enabled will cycle their output off, and then on if "All Outputs Off" is selected

Module Setup

Power Cycling

Delay Time: Set the time in seconds (0–60 seconds) that will be used as the "Power Cycling" time delay for each output that has the "Power Cycling" feature enabled.



Module Setup (Click "Save Settings" when finished)

Power Cycling	
Delay Time:	<input type="text" value="0"/> second(s) (0 - 60)
This sets the delay time before energizing an output when the output is power cycled.	

Alarm Reporting	
When an alarm is triggered on this module,	
Activate Alarm Form C Contact:	<input checked="" type="checkbox"/>
Send E-mail:	<input type="checkbox"/>

Alarm Reporting

Activate Alarm Form C Contact: Select this checkbox to have the rear panel alarm contacts change state for an alarm condition. The default setting is Enabled.

Send E-mail: Select this checkbox to have an e-mail sent to the e-mail addresses set up on the communications page for an alarm condition (see Section 4.7.3). The default setting is Disabled.

Module Output Configuration

Module Output Configuration (Click "Save Settings" when finished)

Select an Output to edit	
<input checked="" type="radio"/> #1: Radio 1	<input type="radio"/> #3: RF Amplifier
<input type="radio"/> #2: Radio 2	<input type="radio"/> #4:

NOTE: Each output on the LDM has an individual screen. Any changes made below will only affect the selected output. Save Setting before changing the selected output.

Select an Output to edit

Select the output to be edited in this section. Make any required changes, and then click on the Save Settings button at the bottom of the page to save any edits.

Output Settings

Output Label: Enter a descriptive label for the selected output channel. The default setting is blank.

Output State after Power Loss: Sets the state for the output after the LDM loses all input power, then recovers. The default setting is Restore Last State. Select one of the following:



Output #1 Settings	
Output Label:	Radio 1
Output State after Power Loss:	Restore Last State ▼
Circuit Breaker Rating:	-- ▼
Ignore Circuit Breaker Status:	<input type="checkbox"/>
Enable Power Cycling:	<input type="checkbox"/>
If Power Cycling is enabled, "Delay Time" must be set above.	
Circuit Breaker Rating is optional and is for informational purposes only.	

- **Restore Last State:** This will return the output relay to the state prior to the reset event (default).
- **Enable Output:** This will turn the output on, regardless of its previous state.
- **Disable Output:** This will turn the output off, regardless of its previous state.

Circuit Breaker Rating: Select the current rating of the circuit breaker installed in the output channel. This field is optional and is for informational purposes only.

Ignore Circuit Breaker Status: Select to disable alarms from this output. Will prevent false alarms on an unused channel. The default setting is Disabled.

Enable Power Cycling: Select this box to enable output power cycling for this output. Enabled outputs will automatically be re-enabled after the "Power Cycle Delay Time" whenever the output is disabled using the Output Off button on the "SETTINGS & CONTROL" tab, or when the "Network Watchdog" is triggered. This feature is useful for remotely resetting power to a router or other hardware required for the network connectivity of the unit. The default setting is Disabled.

NOTE: The Power Cycle Delay time must be set with duration long enough for the connected network hardware to fully reset for this function to be effective. Multiple outputs that are disabled using Power Cycling will be reenabled in sequence from output #1 to output #4.

Output Load-Shedding

Load shedding will disable specified outputs when the system DC voltage reaches a preset threshold for at least 30 seconds. This will save battery capacity for mission-critical load devices by turning off non-critical load devices. Loads will be reconnected if "Load-Shedding Auto Recovery" is enabled, and the DC voltage exceeds the "Recovery Threshold" for 60 seconds.



Output #1 Load-Shedding		
Enable Load-Shedding:	<input type="checkbox"/>	
Load-Shedding Threshold:	<input type="text" value="10.5"/> VDC	(9.0 - 58.5)
Recovery Threshold:	<input type="text" value="12.0"/> VDC	(10.5 - 60.0)
Enable Load-Shedding upon AC Failure condition:	<input type="checkbox"/>	
Load-Shedding Auto Recovery:	<input checked="" type="checkbox"/>	

If enabled, Load-Shedding will disable this Output if the system DC voltage drops below the Load-Shedding Threshold value for 30 seconds or longer.

Enable Load-Shedding: Select this box to enable load-shedding on this output. The default setting is Disabled.

Load-Shedding Threshold: Set the DC voltage (9.0–58.5 VDC) at which the selected output will be disabled. Default setting is 10.5 VDC.

Recovery Threshold: Set the DC voltage (10.5–60.0 VDC) at which the selected output will automatically be reconnected. This value must be at least 1.5 V above the "Load-Shedding Threshold" voltage. The default setting is 12.0 VDC.

Enable Load-Shedding upon AC Failure condition: Select this box to disable the output when an AC failure condition regardless of DC voltage levels. If this option is selected, the Load-Shedding DC bus voltage thresholds are not used and will be greyed out. The default setting is Disabled.

Load-Shedding Auto Recovery: Select this box to allow the output to be automatically reconnected when the bus voltage is above the "Recovery Threshold".

If the "Enable Load-Shedding upon AC Failure condition" option is selected, the output will instead be reconnected when AC input power is restored.

The output must be manually re-enabled using the "Output ON" button if the "Load-Shedding Auto Recovery" function is not enabled. The default setting is Disabled.

Output Over-Current Alarm

Output #1 Over-Current Alarm		
Over-Current Threshold:	> <input type="text" value="0.0"/> A	(0 - 20)
<small>When an Over-Current condition occurs on this Output,</small>		
Disable this Output:	<input type="checkbox"/>	
<small>This alarm will have no effect if the threshold is set to 0 Amps.</small>		

Over-Current Threshold: Set the current that will trigger an overcurrent alarm on this output. Output current above this level for at least 5 seconds will trigger the Over-Current Alarm. Disable this alarm by setting the threshold to 0 amps. The default setting is 0 (Disabled).

Disable this Output: Select this checkbox to disable the output if an over current alarm occurs. The default setting is Unselected.

Output Under-Current Alarm

Output #1 Under-Current Alarm	
Under-Current Threshold:	< <input type="text" value="0.0"/> A (0 - 20)
This alarm will have no effect if the threshold is set to 0 Amps.	

Under-Current Threshold: Set the current that will trigger an undercurrent alarm on this output. Output current below this level for at least 5 seconds will trigger the Under-Current Alarm. Disable this alarm by setting the threshold to 0 amps. The default setting is 0 (Disabled).

Output Scheduled Power Cycle

Output #1 Scheduled Power Cycle	
Enable Scheduled Power Cycle:	<input type="checkbox"/>
Scheduled Day of Week:	Su: <input type="checkbox"/> Mo: <input type="checkbox"/> Tu: <input type="checkbox"/> We: <input type="checkbox"/> Th: <input type="checkbox"/> Fr: <input type="checkbox"/> Sa: <input type="checkbox"/>
Scheduled Time:	<input type="text" value="09"/> : <input type="text" value="00"/> (HH : MM)
Scheduled Power Cycle will be disabled if NTP synchronization is not configured, or if Power Cycling "Delay Time" is not set.	

Enable Scheduled Power Cycle: Select this box to schedule a recurring power cycle of the output, which will reboot the equipment connected to the output channel. The default setting is Disabled.

NOTE: A delay time must be entered in the Power Cycling "Delay Time" field for this function to work. Power for a cycled channel will be held in the off state for the duration set by the Delay Time, then will be turned back on.

NTP Time Synchronization must be enabled on the Communications Basic Setup page to enable scheduled power cycles

Scheduled Day of Week: Set the day of the week, from Sunday to Saturday, that the scheduled recurring power cycle should occur. Multiple days can be selected at once.

Scheduled Time: Set the time of day that the scheduled recurring power cycle should occur.


NOTE: Save Settings for each channel, and then repeat the setup process for all four output channels to be used.

4.6 Alarms

Use this tab to see the alarms on this unit and to control their settings.

4.6.1 STATUS

This tab shows all active alarms and up to 32 historic alarms. The history will be cleared after the ICM is rebooted.



Modular Power System
Modular Power Series 2 (48V)
IP Address: 192.168.0.167
Firmware: v0.36
[Logout]

STATUS **SETTINGS & CONTROL**

Alarm Status

Active Alarms

Module:	Alarm:	Time Set:	Status:
ICM	Battery 4 Comm Error	01/01/20 00:17:43	ACTIVE

Alarm History

Module:	Alarm:	Time Set:	Time Cleared:
#4	Breaker 1 Open	01/01/20 00:19:21	01/01/20 00:19:34
#4	Breaker 2 Open	01/01/20 00:19:19	01/01/20 00:19:33

Active Alarms

Shows the module that the alarm is on; the name of the alarm; the time that the alarm started and the status of the alarm (ACTIVE).

Alarm History


Shows the module that the alarm is on; the name of the alarm; the time that the alarm started; and the time that the alarm cleared.

4.6.2 SETTINGS & CONTROL

Use this tab to set up the four remote form-c alarm monitoring inputs and the system current limit alarm.

Alarm Input

Alarm Name: Set a meaningful name to suit the installation (these will be used for e-mailed alarm messages).




Contact Type: Set the form-C behavior for each device to be monitored (Not Used, Normally Open, Normally Closed). Select Not Used for all unused alarm input channels. The default setting is Not Used.

Activate Alarm Form C Contact: Select this checkbox to have the unit send a form-C alarm for an alarm condition. The default setting is Disabled.

Send E-mail: Select this checkbox to have an e-mail sent to the e-mail addresses set up on the communications page for an alarm condition (see Section 4.7.3).

System Current Limit Alarm



Current Limit Alarm Delay: Set the delay time (0–20 minutes) that the system current limit alarm will be triggered when the system current hits the Current Limit. The default setting is 0.

NOTE: Save Settings before selecting a different tab.

4.7 Communications


Use this tab to configure the basic system parameters, network settings, e-mail settings, user setup, and maintenance functions.

4.7.1 BASIC SETUP

Use this tab to configure the unit's name, set the date and time and enable the watchdog timer and data logging features.

Power System Device Info

Device Name: Enter a descriptive name for the system. This name will be used in all e-mail messages.



The screenshot shows the 'Power System Device Info' configuration page. The page title is 'Communications - Basic Setup'. The 'Power System Device Info' section contains the following fields:

- Device Name:** Modular Power System
- Model:** ICT-IPS (Modular Power Series 2)
- Hardware:** Version 01
- Serial Number:** 340000123
- Site Location:** (empty field)

Model: Shows the model number and series name.

Hardware: Shows the hardware version.

Serial Number: Shows the serial number.

Site Location: Enter the site details. This information is optional.


Date and Time Settings

Current System Time: Shows the current system date and time.

Synchronize with NTP Server: Select this checkbox to synchronize with NTP Server. The default is Enabled.

NTP Server: Set an NTP server address here (i.e., time.nist.gov) to automatically load network time.

Time Zone: Set the time zone this unit will be using.



The screenshot shows the 'Date and Time Settings' configuration page. The page contains the following settings:

- Current System Time:** 01/01/20 01:38:58
- Synchronize with NTP Server:**
- NTP Server:** (empty text field)
- Time Zone:** GMT (dropdown menu)
- Automatically Adjust for DST:**
- Set Time Manually:**
- Date (MM/DD/YY):** 01 / 01 / 20
- Time (HH:MM:SS):** 01 : 38 : 58

Automatically Adjust for DST: Select this checkbox to automatically adjust the time for Daylight Savings Time when synchronizing the clock with a NTP Server. The default is Disabled.

Set Time Manually: Select this checkbox to enable manually setting the time and date. The default is Disabled.

Network Watchdog

Network Watchdog

Watchdog Timeout: minute(s) (1 - 80)

Maximum Cycle Attempts:

Set Maximum Cycle Attempts to 0 for no limit.

Select a Watchdog to edit:

#1: (Disabled)
 #2: (Disabled)
 #3: (Disabled)
 #4: (Disabled)
 #5: (Disabled)
 #6: (Disabled)

Watchdog Enabled:

Primary IP Address:

Secondary IP Address:

LDM Target Outputs (Module #4): 1: 2: 3: 4:

System Reset Targets: System DC Output:
Intelligent Controller Module:

Watchdog Timeout: Set a time in minutes (1–80 minutes) for the unit to wait with no ping response from either IP address before initiating a reset. The default is 10 minutes.

Maximum Cycle Attempts: This setting will limit the maximum number of times the unit can attempt to cycle power to the output(s). If network connectivity is restored the attempts counter is reset. Rebooting the unit will also reset the counter. Set Maximum Cycle Attempts to zero for no limit. The default is 0.

Select a Watchdog to Edit: Select one of the six independent watchdogs to configure. Each watchdog, if enabled, will cause the unit to periodically ping up to two remote IP addresses to verify network connection status. If there is no response from either address, the unit will cycle power on all target outputs that are configured below. This feature is useful for rebooting a router or other network device that is powered by one of the LDM outputs, to help recover the network IP connection when one of these devices becomes unresponsive.

Watchdog Enabled: Select this checkbox to enable the selected network watchdog. The default is Disabled.

Primary IP Address: Set a primary IP address for the selected watchdog to monitor. If left blank the unit will monitor the Gateway IP address listed in the Network Setup page.

Secondary IP Address: Set a secondary IP address for the unit to monitor to verify network status (optional).

NOTE: The Network Watchdog will only trigger if both the Primary and Secondary IP addresses fail to respond.

LDM Target Outputs (Module #): Set which LDM output(s) to power cycle when the watchdog detects a communications failure. The power will be restored after a delay determined by Power Cycling Delay Time (see Section 4.5.2). This setting is only available if the optional Load Distribution Module is installed.

System Reset Targets: Set system reset targets (either the main System DC Output, or the Intelligent Controller Module) to be cycled when the watchdog detects a communications failure.

If System DC Output is selected, the watchdog will cycle all output power. The power will be restored after a delay determined by Auto-Restart Delay (see Section 4.2.2). LDM Target Outputs cannot be selected if System DC Output is selected.

If Intelligent Controller Module is selected, the watchdog will reboot the ICM and Ethernet controller. This does not affect power to the outputs.

Data Logging

Download Data Log: Click on this button to download a running record of all the key system parameters and alarms in CSV format. This record captures and stores data once per minute for the last 30 days.

Data Logging	
Data Log:	<input type="button" value="Download Data Log (CSV)"/>
Log Start Date:	01/01/20 00:00:59
<hr/>	
Battery Log:	<input type="button" value="Download Battery Log (CSV)"/>
<hr/>	
Event Log:	<input type="button" value="Download Event Log (CSV)"/>

Log Start Date: Shows date and time that the data log started.

Download Battery Log (CSV): Click on this button to download a running record of all the key battery parameters in CSV format. This also records the status and any protection, error, or warning alarm that the battery may flag to the power system. This record captures and stores data once per minute.

NOTE: Refer to the battery datasheet and specification to interpret and analyze the reported hexadecimal or decimal value.

Download Event Log (CSV): Click on this button to download the Event Log in CSV format. This log keeps a record of alarm events, device logs, configuration changes and other events.



NOTICE

Updating the ICM firmware will delete the current data log files. Download the logs before updating the ICM firmware.

NOTE: Save Settings to enable any changes made.


4.7.2 NETWORK SETUP

Use this tab to configure the unit's network settings.



NOTICE

Saving any changes to the network settings will cause the ICM to re-start, causing momentary loss of communications.



The screenshot shows the 'Modular Power System' web interface. The top right corner displays system information: 'Modular Power Series 2 (48V)', 'IP Address: 192.168.0.83', and 'Firmware: v0.55'. The main navigation menu on the left includes 'System', 'Power Modules', 'Battery Backup', 'Load Distribution', 'Alarms', 'Communications', and 'Help'. The 'SETTINGS & CONTROL' section is active, with sub-tabs for 'BASIC SETUP', 'NETWORK SETUP', 'E-MAIL SETUP', 'USER SETUP', and 'MAINTENANCE'. The 'Network - IPv4' configuration section is expanded, showing fields for MAC Address (D8:47:8F:57:2B:83), Enable DHCP (checked), IP Address (192.168.0.83), Subnet Mask (255.255.255.0), Gateway (192.168.0.100), Primary DNS (192.168.0.102), and Secondary DNS (9.9.9). Below this, the 'Network - IPv6' section is also visible, showing 'Current IPv6 Addresses' (fe80::da47:8fff:fe57:2b83), 'Static IPv6 Address', 'Prefix Length' (64), and 'IPv6 Gateway'.

Network – IPv4

MAC Address: Shows the MAC address assigned to the unit. It is also shown on the LCD Network Status screen.

Enable DHCP: Select this checkbox if the network uses a DHCP server to automatically assign IP addresses. The default is Enabled.

To manually assign a static IP address to the unit uncheck this box, then set the following parameters.

IP Address: Set a unique IP address for the unit.

Subnet Mask: Set the mask for the subnet the unit is located on.

Gateway: Set the IP address of the default router (Gateway) used for connecting attached devices to different networks.

Primary DNS: Set the IP address of the Primary DNS Server for the network.

Secondary DNS: Set the IP address of the Secondary DNS Server for the network.

Network – IPv6

Current IPv6 Addresses: Displays the IPv6 addresses assigned to the unit. An IPv6 Link-Local address will be configured automatically. Addresses can also be configured by the router through Router Advertisements.

Static IPv6 Address: Set a unique static IPv6 address for the unit. Configuring a static IPv6 address is optional.

Prefix Length: Set the IPv6 prefix length for the network. The default value is 64.

IPv6 Gateway: Set the gateway IPv6 address for the network (optional).

Web Server

Web Server	
HTTP Port:	<input type="text" value="80"/>
HTTPS Port:	<input type="text" value="443"/>
Warning: Changing these settings may affect your ability to access the Power System.	



NOTICE

Changing the web server port numbers may cause loss of communication with the unit.

The following ports may be changed within a range of 1 to 65,565, if required.

HTTP Port: Set the port used for HTTP traffic between the unit and the browser. The default HTTP port is "80", and if this is changed, the new HTTP port number must be appended to the URL used to access the unit (e.g., use URL "http://192.168.0.180:8000" for IP address "192.168.0.180", port "8000").

Setting the HTTP Port to zero will disable HTTP access to the unit.

HTTPS Port: Set the power used for HTTPS traffic between the unit and the browser. The HTTPS (HTTP Secure) protocol uses encrypted data transfer between web browsers and servers for higher security. The default HTTPS port is "443". Append any changed HTTPS port to the end of the URL for the unit.

To access the unit through a secure HTTPS connection, use "https://" at the start of the unit's URL (e.g., "https://192.168.0.180:8888" for IP address "192.168.0.180", HTTPS port "8888").

Setting the HTTPS Port to zero will disable HTTPS access to the unit.

SNMP

SNMP	
Enable SNMP:	<input type="checkbox"/>
SNMP Version:	v1/v2c <input type="button" value="v"/>
Enable SNMP Write Access:	<input type="checkbox"/>
SNMP Control Access:	Output Control <input type="button" value="v"/>
SNMP Contact Information:	<input type="text"/>
v1/v2c Settings:	
Read Community:	public <input type="text"/>
Write Community:	write <input type="text"/>
v3 Settings:	
User Name:	<input type="text"/>
Authentication Protocol:	None <input type="button" value="v"/>
Authentication Password:	<input type="text"/>
Privacy Protocol:	None <input type="button" value="v"/>
Privacy Password:	<input type="text"/>
The SNMP MIB file for this device can be downloaded [HERE].	

SNMP (Simple Network Management Protocol) is an industry standard protocol for network management software. Enabling the SNMP function on the unit will allow standard SNMP management software to connect to the SNMP agent running on the unit and read real-time system information such as bus voltage, and channel currents. The unit can send SNMP traps to the external management software when an alarm or fault occurs.

The information available from the SNMP agent is described in a MIB (Management Information Base) file, which can be downloaded from the ICT website: <https://ict-power.com/resources/tools-utilities/>.

The MIB file can also be downloaded from within the GUI. There are links in the SNMP section of the Communications Network Setup tab and on the Help tab. The unique unit MIB file must then be imported into the external SNMP management software.

Enable SNMP: Select this checkbox to enable the SNMP agent. The default setting is Disabled.

SNMP Version: Set the SNMP version (v1/v2c, v3, or All) supported by the SNMP agent. If "All" is selected, all SNMP versions will be supported simultaneously. The appropriate settings for the selected SNMP version will need to be configured.

Enable SNMP Write Access: Select this checkbox to enable remote SNMP control of the system output and individual LDM output channels. If this box is unchecked, all information available from the SNMP agent will be read-only.

SNMP Control Access: Set the level of unit control that is allowed through SNMP. This setting is only available if Enable SNMP Write Access is enabled.

- **Output Control:** Allows remote SNMP control of the system output and LDM channel outputs only.
- **Full Device Control:** Allows SNMP client to set all unit settings through SNMP. This setting requires a different MIB file which can be downloaded from the ICT Website: <https://www.ict-power.com/resources/tools-utilities/>.

SNMP Contact Information: Set contact information, such as an operator name and phone number for the unit, which can be read via SNMP queries (this information is optional).

v1/v2c Settings

Read Community: Enter the community string/password here for read-only SNMP access. The default read community string is "public".

Write Community: Enter the community string/password here for read/write SNMP access. The default write community string is "write".

NOTE: The community strings should be changed to unique passwords before enabling SNMP, as the defaults are well known.

v3 Settings

User Name: Set the username for SNMPv3 access.

Authentication Protocol: Set the SNMPv3 authentication protocol (None, MD5, or SHA).

Authentication Password: If an authentication protocol is selected, set the authentication password.

Privacy Protocol: Set the SNMPv3 privacy protocol (None, or AES).

Privacy Password: If a privacy protocol is selected, set the privacy password.

SNMP Traps

SNMP Traps	
Trap Version:	v1 ▾
Trap Community:	public
Trap User Name:	
Authentication Protocol:	None ▾
Authentication Password:	
Privacy Protocol:	None ▾
Privacy Password:	
Trap IP Addresses:	

Trap Version: Set the SNMP version (v1 or v3) for SNMP traps sent from the system. The appropriate settings for the selected SNMP version will need to be configured.

Trap Community: Set the community string/password that will be sent with all SNMPv1 traps. Some trap receivers can filter based on Trap Community. This field is only used for v1 traps.

Trap User Name: Set the username for SNMPv3 traps. This field is only used for v3 traps.

Authentication Protocol: Set the authentication protocol for SNMPv3 traps (None, MD5, or SHA).

Authentication Password: If an authentication protocol is selected, set the authentication password for SNMPv3 traps.

Privacy Protocol: Set the privacy protocol for SNMPv3 traps (None, or AES).


Privacy Password: If a privacy protocol is selected, set the privacy password for SNMPv3 traps.

Trap IP Addresses: Set the IP addresses for up to two devices that will receive SNMP traps from the unit.

NOTE: Save Settings before selecting a different tab.

4.7.3 E-MAIL SETUP

Use this tab to configure all e-mail settings to enable automatic e-mail notifications directly from the unit. The information required for this is available from the Network Administrator, or Internet Service Provider (ISP).



The screenshot shows the 'E-MAIL SETUP' tab in the 'SETTINGS & CONTROL' section. The interface includes a left-hand navigation menu with options like 'System', 'Power Modules', 'Battery Backup', 'Load Distribution', 'Alarms', 'Communications', and 'Help'. The 'Communications - E-mail Setup' form contains the following fields:

- SMTP Server: [Text input field]
- SMTP Port: [Text input field with value 25]
- SMTP Server requires SSL: [Checkbox]
- Sender E-mail Address: [Text input field]
- Recipient E-mail Addresses: [Text input field]
- SMTP User Name: [Text input field]
- SMTP Password: [Text input field]
- Minimum E-mail Interval: [Text input field with value 0] minute(s)

Below the form, there are two lines of small text: "Use commas to separate multiple Recipient E-mail Addresses." and "Leave the SMTP User Name & Password blank if the SMTP Server does not require authentication."

E-mail

SMTP Server: Set the name or the IP address of the SMTP server used for sending outgoing e-mail (e.g., "smtp.gmail.com").

SMTP Port: Set the port used by the SMTP server. The default setting is 25.

SMTP Server requires SSL: Select this checkbox if the SMTP server requires an encrypted SSL connection. This box should normally be checked if the SMTP port used by the SMTP server is 465. If the SMTP server uses STARTTLS (normally port 587), this box should be unchecked.

Sender E-mail Address: Set an e-mail address that will appear as the sender for all e-mail notifications sent from the unit.

Recipient E-mail Addresses: Set one or more e-mail addresses that are to receive all e-mail notifications from the unit. Use commas to separate multiple addresses.

NOTE: This field can also be used to send text message notifications to a phone (see Section 7.7).

SMTP User Name: Set an SMTP user name here, if required by the SMTP server. Leave this field blank if the server does not require authentication.

SMTP Password: Set an SMTP password here, if required by the SMTP server. Leave this field blank if the server does not require authentication.

Minimum E-mail Interval: Set a minimum interval in minutes (0–60 minutes) between e-mail notifications. This time interval is used to prevent an un-intended flood of e-mail alarm notifications that could occur when an alarm limit is incorrectly configured, for example. The default setting is 0.

General E-mail Notifications

General E-mail Notifications	
Send an E-mail Notification when:	
AC Input Power is lost:	<input type="checkbox"/>
A Power Module failure occurs:	<input checked="" type="checkbox"/>
A Module is offline:	<input type="checkbox"/>
System Current Limit is triggered:	<input type="checkbox"/>
Intelligent Controller Module reset:	<input type="checkbox"/>
The Network Watchdog triggers:	<input type="checkbox"/>
Scheduled Power Cycle occurs:	<input type="checkbox"/>

Set these options to receive an e-mail when one or more of these events occurs:

AC Input Power is lost: Select this checkbox to receive an e-mail notification when the AC input drops below a functional level.

A Power Module failure occurs: Select this checkbox to receive an e-mail notification when any of the installed Power Modules stop functioning.

A Module is offline: Select this checkbox to receive an e-mail notification when a module loses communication with the ICM.

System Current Limit is triggered: Select this checkbox to receive an e-mail notification when the "Total System Current" hits the "Current Limit".

Intelligent Controller Module reset: Select this checkbox to receive an e-mail notification of an ICM reset for any reason.

The Network Watchdog triggers: Select this checkbox to receive an e-mail notification when the "Network Watchdog" triggers due to a loss of the network connection.

Scheduled Power Cycle occurs: Select this checkbox to receive an e-mail notification after a scheduled power cycle of an output has occurred.

NOTE: Save Settings before selecting a different tab.

4.7.4 USER SETUP

Use this tab to set up and configure the usernames and passwords for up to 10 users. Set the level of access to the unit settings allowed for each user. Click on the Save Settings button at the bottom of the page to save any password changes.


The unit has no password assigned by default, so an Administrator password should be assigned to the unit for improved security.

User Accounts

Shows the User Name and Access Level.

Edit User

Select to edit an existing user account. Set the access level for each user.




NOTICE

Record the new password(s) for future access. If the Administrator password is lost the unit must be reset to return the password to the blank default setting, causing loss of all other user settings (see Section 3.3).

Access Level: Set the access level:

- **Administrator:** This level has full access to the unit settings and can set up users and change passwords ("admin" is the default user).
- **Control:** User has read-only access to the unit, but can enable or disable the outputs, and change some of the basic settings.
- **View-Only:** User can only view status, cannot change any settings.



Password: Enter the new password for the chosen user.

Password (confirm): Re-enter the new password to confirm the entry.

Confirm Changes

User Name: Enter admin user name to confirm these changes are valid.

Password: Enter the admin password to confirm the changes are valid.


Add New User

User Name: Set user name.

Access Level: Set access level.

Password: Set password.

Password (confirm): Confirm password.



MPS Series 2
Modular Power Series 2 (48V)
IP Address: 192.168.0.71
Firmware: v0.50
[Logout]

SETTINGS & CONTROL

System
Power Modules
Battery Backup
Load Distribution
Alarms
Communications
Help

BASIC SETUP NETWORK SETUP E-MAIL SETUP USER SETUP MAINTENANCE

Communications - User Setup

Add New User

User Name:

Access Level:

Password:

Password (confirm):

Use a password length of 8 to 32 characters. Passwords are case sensitive.

Confirm Changes

Enter your current Administrator user name and password to confirm changes.

User Name:

Password:

Copyright © 2025 Innovative Circuit Technology Ltd.

Confirm Changes


User Name: Enter admin user name to confirm these changes are valid.

Password: Enter the admin password to confirm the changes are valid.

Add User to save and return to the previous screen.

4.7.5 MAINTENANCE


Use this tab to reset the unit (soft reset), restore the factory default settings, or send a test e-mail to verify e-mail functionality.



Reset Intelligent Controller Module

Select the "Reset" button to restart the ICM. The LDM channel output states will be restored according to the "Output State after Power Loss" setting for each output on the "Output Setup" page. All other settings are maintained during the reset.

Restore Factory Default Settings



Select the "Restore" button to restore all settings to the original factory default values, including the user passwords. To restore the network settings and passwords only, see the Password Reset section (this feature is only available to the system Administrator) (see Section 3.2.6).



NOTICE

Restoring the unit to Factory Default settings may cause loss of network communications due to loss of custom changes to any network settings.

To reset only the IP address and Administrator password to the original default values, select "Reset Comm Settings" (see Section 3.2.6) in the front display panel menu.

Export and Import Settings

Export and Import Settings

Export the current configuration of the Power System to a file, or import a previously saved configuration file.

Select the "Manage Settings" button to access the Export and Import Settings page shown below. Use this page to export all system settings to an encrypted .cfg file which may be imported into other units to speed configuration. The export does not include Administrator password, Network nor Web Server settings. Use the Import Settings section on other systems to locate this file and then import it to any other Modular Power Series 2.

Export and Import Settings

Export Settings

Save all settings to a configuration file:

Import Settings

Import settings from a previously saved configuration file:

Select a ".cfg" file below, then click the "Import Settings" button.
The unit will restart automatically after the import is complete.

Importing settings will overwrite all current settings
(except for Administrator password, Network and Web Server settings).

Configuration File: No file chosen

Copyright © 2025 Innovative Circuit Technology Ltd.

Security Certificates

Security Certificates

Install SSL/TLS certificates for secure HTTPS access.

Select the "Manage Certificates" button to access the Manage Certificates page shown below. Use this page to import a new HTTPS Security Certificate to replace the default certificate. Both the Certificate File and Private Key File must be imported individually in PEM format. An optional

Private Key Password can be entered if the Private Key is password protected.

Manage Certificates

Certificate & Key files must be PEM formatted.
Certificate changes will take effect after Intelligent Controller Module reset.

HTTPS Security Certificate

Security Certificate: Factory Default

Certificate File: No file chosen

Private Key Password:

Private Key File: No file chosen

Copyright © 2025 Innovative Circuit Technology Ltd.

After a certificate has been successfully imported, a "Delete" button will be available which will erase the imported certificate.

The Intelligent Controller Module must be restarted before any certificate changes will take effect.

Firmware Update

Firmware Update

Update the Power System with the latest firmware.

Download the latest Modular Power Series 2 firmware file from the ICT website (ict-power.com) to a local computer. Select the "Update Firmware" button to access the Firmware Update page shown below.

Use this page to update the ICM and other module firmware on the power system.

Update the control module by clicking the "Choose File" button to link the downloaded firmware then click the "Update Now" button. Note that the system settings will not be changed. Do not remove AC power during the update process.

Firmware Update

Update Intelligent Controller Module

To update the Intelligent Controller Module firmware:

1. Download the latest firmware from ict-power.com
2. Extract the firmware file to your local disk. Firmware files have a ".cry" extension.
3. Select the firmware file below, then click the "Update Now" button to begin the update.

Do not disconnect power to the device during the update!

The device restarts automatically after the update has completed.

Firmware File: No file chosen

Update Installed Modules

Update the firmware on other modules installed in the Power System.

Copyright © 2025 Innovative Circuit Technology Ltd.



NOTICE

Updating the ICM firmware will delete the current log files.
Download the logs before updating the ICM firmware.

Update other modules by Selecting the "Update Module Firmware" button to access the Module Firmware Update page shown below.

Module Firmware Update

To update the firmware of an installed module:

1. Ensure that AC power is connected, and the system DC output is enabled.
2. Select the module to be updated, then click on the "Set" button.
3. Select the firmware file, then click the "Update Now" button to begin the update.

Do not disconnect power to the system during the update!

During the update, the selected module will go offline and will not deliver DC power.

Module:

Selected Module: 1

Current Firmware Version: v1.54

Firmware File: No file chosen

Copyright © 2025 Innovative Circuit Technology Ltd.

Select the module to be updated by using the drop-down menu and clicking "Set" button (refer to Figure 24 for the module number identification). The Selected Module field and Current Firmware Version field will then be updated with the information from the selected module.




Figure 24. Module Number Identification


Click the "Choose File" button and link to the update firmware then click the "Update Now" button. The upgrade will take up to 3 minutes to complete.



NOTICE


Do not remove or insert any modules or disconnect power to the Modular Power Series 2 while the upgrade is in progress, or the unit may become unusable.

"Update Complete" will be displayed after the upgrade successfully completes.



Repeat this process for each module that is to be updated.

Send Test E-mail



Select the "Send Test E-mail" button to send a test e-mail to the e-mail recipients listed on the E-mail Setup page (see Section 4.7.3).

Ping Diagnostics Tool

Ping Diagnostics Tool

Use this tool to verify connectivity to any network device.

Host or IP address:

Use this feature to verify connectivity of any network connected unit. Enter the hostname or IP address of the target device, and then click the "Ping" button to check if the device is active.

4.8 Help


This tab has helpful links to ICT's website.

Instruction Manual

Click the "HERE" button to download the ICT Modular Power Series 2 Instruction Manual from ICT's website.

SNMP

Click the "HERE" button to download the SNMP MIB file.



The screenshot shows the web interface for the ICT Modular Power System. The top left features the ICT logo and the tagline "The Power of Reliability". The top right displays system information: "Modular Power System", "Modular Power Series 2 (48V)", "IP Address: 192.168.0.83", "Firmware: v0.35", and a "Logout" link. A left-hand navigation menu includes "System", "Power Modules", "Battery Backup", "Load Distribution", "Alarms", "Communications", and "Help" (which is currently selected). The main content area is titled "Help" and contains two sections: "Instruction Manual" with a link [HERE] to download the manual, and "SNMP" with a link [HERE] to download the MIB file. A copyright notice at the bottom reads "Copyright © 2025 Innovative Circuit Technology Ltd."

5.0 OPERATION: PARALLEL (Not applicable)

**6.0 OPERATION: STANDARD POWER SHELF
(Not applicable)**

7.0 FAQs

7.1 How do I connect the temperature sensor to the battery?

- Mount the sensor to the mid-level side of the middle battery in a set using the adhesive backed clip.
- See step # 3 of Section 2.8 for more information.

7.2 What information do I need to set up my battery?

Review the battery manual for the correct settings to enter into the GUI to ensure that the battery is correctly configured and to avoid future issues.

7.3 Why are Net Ah count, Run Time Remaining and SOC blank?

- The unit requires the battery to be running at full charge for at least 8 hours with lead-acid, or 1 hour with lithium-ion for the battery net Ah and Run Time Remaining to be displayed.
- See Section 4.4.1 in the user manual.

NOTE: Disconnecting and reconnecting the battery will require the same process as connecting a new battery to the unit.

7.4 How do I configure a router?

To set up the power system with remote internet access when it is located behind a router, Port Forwarding will need to be enabled on the router to forward incoming HTTP or HTTPS traffic to the local IP address of the unit. Refer to the router's user manual for instructions on how to configure Port Forwarding.

7.5 How do I access the web-based configuration utility?

- Check the correct IP address for the system by downloading and running the ICT IP Address Discovery tool from <http://www.ict-power.com/tools-utilities/>.
- Check the network cable connections to the unit and the network.
- Ensure the network card settings on the computer are configured for accessing the IP address of the Modular Power Series 2. To access a unit with the default IP address of 192.168.0.180 the typical network settings for the computer are:
 - IP Address: 192.168.0.100
 - Subnet Mask: 255.255.255.0
 - Gateway: 192.168.0.1



- If the HTTP port of the unit has been changed, append the new port number to the URL used to access the unit (see Section 4.7.2). See the Password Reset Section (see Section 4.7.5) for details on how to reset the port number to the factory default value.
- If the network switch allows the user to manually configure port speed and duplex settings, turn-on "Auto Negotiation" for the switch port that the unit is connected to.
- If VLAN is enabled, check that the VLAN ID configured on the unit matches the VLAN ID set on the user's network. After any changes to the VLAN configuration, make sure to restart the controller to have the changes take effect.

7.6 How do I receive e-mails from the unit?

- See Section 4.7.3 E-MAIL SETUP.
- Verify that the "Send E-mail" checkboxes are selected for any alarm conditions for which the user wishes to receive e-mail notifications.
- Verify the e-mail settings by going to the "Communications/Maintenance" tab on the unit's GUI and clicking on the "Send Test E-mail" button, to send a test message to the designated recipient addresses. The "Send Test E-mail" page will show an error message if the system is unable to send the e-mail.
- Check on the "Communications/E-mail Setup" tab and ensure that the "SMTP Server" field is the correct address for the e-mail provider, and that the "SMTP Port" is correct (Port should be 25 for most servers).
- If the SMTP server requires SSL encryption, ensure that the "SMTP Server requires SSL" checkbox is ticked. Otherwise leave it blank.
- If the SMTP server requires authentication, ensure that the "SMTP User Name" and "SMTP Password" fields are correctly entered.

7.7 How do I receive text message alarm notifications?

The unit can send alarm notifications to a cell phone by configuring the alarm e-mails to be sent to the mobile phone service provider.

To use this feature, check with the user's mobile phone service provider to confirm whether email-to-text messaging is supported and to obtain the correct address format. Alternatively, third-party email-to-SMS services may be used to deliver text message notifications.

7.8 How do I upgrade the firmware?

On the ICT website, click on Resources > Product Firmware and select the product. Download the latest firmware. In the ZIP file will be a



README document with step-by-step instructions or see section "Firmware Update" in Section 4.7.5.



NOTICE

Updating the ICM firmware will delete the current log files. Download the logs before updating the ICM firmware.

7.9 How do I reset the password?

See Section 3.3.

7.10 Why don't I see the BMS RS-485 Communication section?

- If 12-volt or 24-volt Power Modules are installed in the system, the BMS RS-485 Communication section will not be shown.
- The BMS RS-485 Communications are currently supported only for 48-volt batteries from the following brands: Cyclone, EG4 LL, Narada and Power Stage Solutions.

7.11 I have enabled BMS communication, but I cannot see the information of the connected batteries.

- Ensure battery communication cable is properly installed.
- Check that the RJ-45 connector is connected to the RJ-45 port (lower port) on the rear panel.
- Check that the RS-485 end of the cable is connected to the RS-485 port on the battery.

7.12 How do I log out of the GUI?

To log out of the ICT Modular Power Series 2 GUI, click on the Logout link on the top right of the browser window. The system will also automatically log off the user after 20 minutes of inactivity.

8.0 PRODUCT SPECIFICATIONS

8.1 Electrical Specifications

Table 31. Overall Electrical Specifications

Parameters	Rating
AC Input Nominal Rating	120 / 240 VAC; 50 / 60 Hz
AC Input Operating Range	108 to 264 VAC
AC Input Maximum Range	90 to 300 VAC
Input Power Factor (typical)	0.99
Efficiency	Up to 95%
Output V Line Regulation	+/- 0.1%
Network Communication	RJ45 10/100/1000 BASE-T port (IPv4, IPv6, VLAN, HTTP, HTTPS, SMTP, DNS, TCP, UDP, ICMP, DHCP, ARP, SNMP v1/v2c/v3, SNTTP Protocols)
Network Security	Password protection, SSL encryption for HTTPS and SMTP (TLS 1.3)

Table 32. Power Module Specifications (cont'd on next page)

Parameters	Power Shelf	ICT 700-12PM	ICT 700-24PM	ICT 1000-48PM	ICT 1500-24PM	ICT 1500-48PM
AC Input Current (A_{rms} at 230 VAC)	32 A max	3.5 A max.	3.5 A max.	5.0 A max ²	8.0 A max.	8.0 A max.
AC Input Current (A_{rms} at 115 VAC)	40 A max	7.0 A max.	7.0 A max.	10.0 A max ³	8.0 A max.	8.0 A max.
Output Voltage ¹ (Nominal Battery float Voltage) (+/- 0.5%)	-	13.8 VDC	27.6 VDC	55.2 VDC	27.6 VDC	55.2 VDC
Output Voltage Range (adjustable)	-	11.5–15.5 VDC	23–31 VDC	46–60 VDC	23–31 VDC	46–62 VDC
Output Power (max) (230 VAC) @ N+1	4,500 W	700 W	700 W	1,000 W	1,500 W	1,500 W
Output Power (max) (115 VAC) @ N+1	3,000 W	700 W	700 W	1,000 W	900 W	900 W
Output Current (continuous) (230 VAC) @ N+1	162 A	50 A	25 A	18 A	54 A	27 A

Parameters	Power Shelf	ICT 700-12PM	ICT 700-24PM	ICT 1000-48PM	ICT 1500-24PM	ICT 1500-48PM
Output Current (continuous) (115 VAC) @ N+1	150 A	50 A	25 A	18 A	32 A	16 A
Output Derating	2% / °C (above 50°C)					
Efficiency (peak)	-	90%	91%	91%	94%	95%
Output Noise (max mV _{rms})	-	30 mV _{rms}	30 mV _{rms}	60 mV _{rms}	40 mV _{rms}	60 mV _{rms}
Output V Load Regulation	-	1.7%	1.7%	1.2%	1.7%	1.2%

¹ Actual operating point may be lower due to battery charge requirement.

² Current draw when in power saving mode: <15 mA.

³ Current draw when in power saving mode: <30 mA.

Table 33. Battery Management Module Specifications

Parameters	Power System	ICT 700-12PM	ICT 700-24PM	ICT 1000-48PM	ICT 1500-24PM	ICT 1500-48PM
BMM Max Battery Current (per input)	100 A	-	-	-	-	-
BMM Max total Battery Current through LVD	150 A	-	-	-	-	-
BMM LVD Threshold V (Default)	-	10.5 V	21 V	42 V	21 V	42 V
BMM LVD Reconnect V (Default setting)	-	12.5 V	25 V	50 V	25 V	50 V
BMM idle DC Power Draw ¹	<1 W	-	-	-	-	-
Meter Accuracy (Voltage)	BMM voltage readings +/-3%					
Meter Accuracy (Current)	BMM current readings +/-5%, or +/-1 A if current reading is less than 20 A					

¹ AC mains power off; backup battery connected; LVD open.

Table 34. Load Distribution Module Specifications

Parameters	Rating
Outputs per LDM	4 (normally closed)
Max Output Rating (12, 24, or 48 V)	25 A continuous
Voltage Range	10–65 VDC
Channel Current Monitoring	+/-5% accuracy

8.2 Physical Specifications

Table 35. Physical Specifications

Parameters	Configuration
Output Grounding	Power Modules are floating, may be connected with positive or negative ground ¹
Alarm Output	Form-C dry contact, 0.5 A 60 VDC max (voltage-free contact)
DC Connectors: (Output, Battery)	Bus Bar, 5/16-inch bolt hole
Load Distribution Module (LDM) Connectors	8-terminal push-in cage clamp style, 10–24 AWG
Alarm Output Connector	3-pin removable plug, cage clamp type 16–24 AWG
Alarm Input, Bat temp sense Connector	7-pin removable plug, cage clamp type 16–24 AWG
AC Input Connector	3-pin removable plug, cage clamp type 8–22 AWG
Operating Temperature Range	-30 to +60°C ²
Storage Temperature Range	-45 to +85°C
Humidity	(Operating) 10–90% (non-condensing) (Storage) 5–95% (non-condensing)
Cooling	Load controlled fan on Power Modules

¹ Optional BMM and LDM modules are available in positive (-48 volts) or negative (+12/24 volts) ground configuration. Specify at time of ordering.

² Ambient Temperature. De-rate output 2% per °C above 50°C.

Table 36. Heat Dissipation

Module	Rating
IPS	10 BTU/hr
ICT700-12PM	266 BTU/hr
ICT700-24PM	237 BTU/hr
ICT1000-48PM	7 BTU/hr (power save mode) 338 BTU/hr
ICT1500-24PM	327 BTU/hr
ICT1500-48PM	270 BTU/hr
BMMD	10 BTU/hr (idle) 287 BTU/hr (150 A; Battery Voltage: 54 VDC)
LDM	10 BTU/hr (idle) 200 BTU/hr (25 A/channel; System Voltage: 55.2 VDC)

8.3 Regulatory Specifications

Table 37. Regulatory Compliance

Category	Certification
Safety, EMC-Emissions, EMC-Immunity, RoHS (700 W) ¹	UL/CSA 62368-1, ICES-003, FCC Part 15/B, EN 61000-6-2, EN 61000-6-3, EIC 61000-4-5, CE, RCM and RoHS
Safety, EMC-Emissions, EMC-Immunity, RoHS (1,000 W)	UL/CSA 62368-1, ICES-003, FCC Part 15/B, EN 61000-6-1, EN 61000-6-3, EIC 61000-3-2, EIC 61000-3-3, CE, RCM and RoHS
Safety, EMC-Emissions, EMC-Immunity, RoHS (1,500 W)	UL/CSA 62368-1, ICES-003, EN55032, EN 61000-3-2, EN 61000-3-3, IEC 61000-4-5, CE, RCM and RoHS

¹ EMC specifications are valid for 24/48 VDC models only; 12 VDC models are designed to meet these specifications.

8.4 Mechanical Specifications

Table 38. Dimension and Weight

Physical Property	Value
Dimension - L x W x H	16.3 x 19.0 x 1.7 in. (414 x 483 x 44 mm)
Weight	18 lbs. (8.2 kg) ¹ maximum

¹ Weight of unit as shipped with BMMD and LDM. No Power Modules.




Figure 25. Dimensions

9.0 GLOSSARY

• 1RU	One Rack Unit; 1.75-inch (44.55 mm) of rack height
• 2RU	Two Rack Unit; 3.5-inch (89 mm) of rack height
• A, amps	Amperes
• A_{rms}	Amperes (Root Mean Square)
• AES	Advanced Encryption Standard
• Ah	Ampere-Hours
• ANSI	American National Standards Institute
• ARP	Address Resolution Protocol
• AWG	American Wire Gauge
• BMM	Battery Management Module
• BMMD	Dual Battery Management Module
• BMS	Battery Management System
• BTU	British Thermal Unit
• CSV	Comma-Separated Values
• DHCP	Dynamic Host Configuration Protocol
• DNS	Domain Name System
• FCC	Federal Communications Commission
• GUI	Graphical User Interface
• HTTPS	Hypertext Transfer Protocol Secure
• Hr	Hour
• Hz	Hertz
• ICES	Interference-Causing Equipment Standard
• ICM	Intelligent Control Module
• ICMP	Internet Control Message Protocol
• ISO	International Organization for Standardization
• ISP	Internet Service Provider
• LDM	Load Distribution Module
• LVD	Low Voltage Disconnect
• MAC	Media Access Control
• MIB	Management Information Base
• NEC	National Electrical Code
• OEM	Original Equipment Manufacturer
• OLED	Organic Light-Emitting Diode
• PEM	Privacy Enhanced Mail
• RMA	Return Material Authorization
• RoHS	Restriction of Hazardous Substances
• SHA	Secure Hash Algorithms
• SLA	Sealed Lead-acid
• SMTP	Simple Mail Transfer Protocol
• SNMP	Simple Network Management Protocol
• SOH	State of Health
• SOC	State of Charge
• TCP	Transmission Control Protocol
• TCP/IP	Transmission Control Protocol/Internet Protocol
• TLS	Transport Layer Security
• UDP	User Datagram Protocol
• V	Volts
• VAC	Volts, Alternating Current
• VDC	Volts, Direct Current
• VLAN	Virtual Local Area Network
• V_{rms}	Volts (Root Mean Square)
• W	Watts

Find the latest version of this manual here:

<https://ict-power.com/product/modular-power-series-2/>



INNOVATIVE CIRCUIT TECHNOLOGY LTD.

26921 Gloucester Way

Langley, British Columbia, Canada V4W 3Y3

T +1 604.856.6303 (International)

T +1 877.930.0717 (North America Toll-free)

www.ict-power.com