



INCLUDES

Rustic Barn Door Pull Hardware	x1
5mm Allen Key	x1

Use a 3/8" drill bit to drill holes into the door. Holes should be spaced 7-1/16" apart. Use the 5mm allen key to secure the pull to the door as shown in the diagram above.