



MBC/MBC800

Mobile to Base Converter

Follow these simple installation procedures:

1. Install four (4) 22 1/2" radials into the holes in the mount nut and secure them with the allen wrench and installed set screws provided.

2. Install the "L" bracket assembly to your mast with the two hose clamps provided. Use care to position the hose clamps in the slotted area of the "L" bracket.

3. Install your Laird Technologies mobile antenna (using care not to overtighten the coil housing onto the brass bushing) and connect your feed line.

Note: For 406-512 MHz, cut radials to 8 inches



MBC800 pictured with optional B8063 antenna.