

BASIC GREATWALL SLATWALL INSTALLATION

SAFETY REMINDER: USE SAFETY EYE WEAR AND GLOVES.


Step 1: Plan space and quantity requirements, noting electrical wire locations to avoid piercing any wiring. Slatwall can be cut either vertically or horizontally using an electric saw with a thin sharp blade (60-80 teeth). If using a table saw, cut Slatwall facing up. If using a circular saw, cut the Slatwall face down. Locate and mark wood studs. Transfer these locations to the Slatwall panel grooves. Proceed to pre-drill. For a more permanent installation follow step 2, if not proceed to step 3.



Step 2: Apply a construction adhesive, such as Liquid Nails® or Loctite® to the back of the Slatwall.




Step 3: Make sure the Slatwall is right side up. Starting from the bottom up line up the panel on the wall making sure that it is level. Note: The first panel on the wall must be perfectly leveled. All other panels will be aligned from the panel.



Note: If installing at floor level be sure to leave a 1/4" gap between the floor and Slatwall panel for baseboard trim.

Step 4: Screw the Slatwall to the wall in the center of the slot at every wood stud along the top & bottom slats with #6 or #8 drywall flat head screws, be careful not to over tighten the screws. Use self-tapping drywall screws over metal studs. Masonry wall should first be framed with wood studs.



Note: Screw length should be at least 2" if going through drywall into the stud. For heavier items, additional screws can be used along each stud in every other slat.

Step 5: Proceed to the next Slatwall panel, lining up the tongue on the bottom edge with the groove on the top edge of the previous panel. Repeat steps 2-4 until all panels are installed.

